

Ultra Mag Electromagnetic Flow Meter

Installation, Operation and Maintenance Manual

For use with Procomm GO Converter



Standard Model

For use in non-hazardous locations

HL Model

For use in hazardous locations:

- Class I, Division 2, Groups A-D, T5
- Class I, Zone 2 IIC T5

30125-70 Rev. 1.3
March 14, 2023

Contents

SAFETY.....	1
Safety Symbols And Warnings	1
Safety Warnings	1
1.0 DESCRIPTION OF THE FLOW METER.....	2
2.0 UNPACKING THE CRATE AND VERIFYING SERIAL NUMBERS.....	2
2.1 Uncrating.....	2
2.2 Verifying the Serial Numbers.....	2
3.0 PREPARING FOR A NEW INSTALLATION	3
3.1 Sensor Location.....	3
3.2 Remote Mount Converter Location	3
3.3 Pipe Run Requirements	3
3.4 Positioning and Orienting the Sensor.....	4
4.0 FLOW METER INSTALLATION	5
4.1 Wafer Style Meter Installation.....	5
4.2 Flanged Meter Installation	5
4.3 Remote Mount Installation.....	5
5.0 REMOTE MOUNT CONVERTER INSTALLATION	6
5.1 Mounting the ProComm GO Converter.....	6
5.2 Installing Cables through Cable Glands and Conduit.....	6
5.3 Pulling Sensor Cable Through Electrical Conduit	7
5.4 Cable Gland Assignment for Wiring Harnesses	7
6.0 INTERNAL WIRE CONNECTION.....	8
6.1 Terminal Block Diagram and Grounding Lug	8
6.2 Wiring Diagrams	9
6.3 Optional Smart Output Hook Up	10
7.0 EXTERNAL WIRE CONNECTION	10
7.1 Cable Gland Connections	10
7.2 Quick Connect Cabled Ends (Optional).....	11
7.3 Power Options	12
7.4 DC Power Cable (Optional)	12
7.5 4-20mA Current Loop.....	13
7.6 Pulse Output Cable (Optional).....	13
7.7 Solar Panel Option	14
8.0 GROUNDING AND ELECTRICAL INTERFERENCE	15
8.1 Sensor Grounding Methods.....	15
9.0 BATTERY REMOVAL AND REPLACEMENT.....	18
10.0 OPERATION.....	22
10.1 General.....	22
10.2 Activating the Display	22
10.3 Converter Boot.....	22
11.0 CONVERTER CONFIGURATION.....	23
12.0 ERROR MESSAGES FOR TROUBLESHOOTING	24
13.0 REPLACEMENT PARTS	25
14.0 SPECIFICATIONS, WEIGHTS, AND DIMENSIONS	26
14.1 Flow Meter Specifications.....	26
14.2 Flow Meter Dimensions and Weights	28
14.3 ProComm GO Converter Specifications	30
14.4 ProComm GO Converter Dimensions	32
15.0 RETURNING A UNIT FOR REPAIR.....	33
WARRANTY.....	34

SAFETY

Safety Symbols And Warnings

Throughout this manual are safety warning and caution information boxes. Each warning and caution box will be identified by a large symbol indicating the type of information contained in the box. The symbols are explained below:



This symbol indicates important safety information. Failure to follow the instructions can result in serious injury or death.



This symbol indicates important information. Failure to follow the instructions can result in permanent damage to the meter or installation site.

Safety Warnings

When installing, operating, and maintaining McCrometer equipment where hazards may be present, you must protect yourself by wearing Personal Protective Equipment (PPE) and be trained to enter confined spaces. Examples of confined spaces are manholes, pumping stations, pipelines, pits, septic tanks, sewage digesters, vaults, degreasers, storage tanks, boilers, and furnaces.

You must follow all state and local laws, as well as Occupational Safety and Health Administration (OSHA) regulations concerning Personal Protective Equipment and confined-space entry. Specific requirements can be found in the OSHA section of the Code of Federal Regulations: 29 CFR, 1910.132 - 1910.140, *Personal Protective Equipment*; and CFR Title 29, Part 1910.146, *Permit-Required Confined-Spaces*.



WARNING!

Incorrect installation or removal of meters can result in serious injury or death. Read the instructions in this manual on the proper procedures carefully.



WARNING!

Never enter a confined space without testing the air at the top, middle, and bottom of the space. The air may be toxic, oxygen deficient, or explosive. Do not trust your senses to determine if the air is safe. You cannot see or smell many toxic gases.



WARNING!

Never enter a confined space without the proper safety equipment. You may need a respirator, gas detector, tripod, lifeline, and other safety equipment.



WARNING!

Never enter a confined space without standby/rescue personnel within earshot. Standby/rescue personnel must know what action to take in case of an emergency.

1.0 DESCRIPTION OF THE FLOW METER

Ultra Mag meters are available with integral or remote mount converters. Standard display features include forward, reverse and net flow totalizers, flow rate, alarm monitoring, and automatic self diagnostics to ensure integrity. All data and values are in selectable units of measurement. System compatibility is assured with a choice of current, pulse and serial data. Please refer to the converter manual provided with your meter.

Ultra Mag operating parameters are set via the electronics keypad. The software features multilevel password protection capability to prevent inadvertent program or setting changes. Data is stored in nonvolatile memory.

The flanged end tube design permits use in a wide range of applications. The fabricated tube is stainless steel with steel or stainless steel flanges and incorporates the UltraLiner, an NSF approved fusion-bonded epoxy liner.

2.0 UNPACKING THE CRATE AND VERIFYING SERIAL NUMBERS

2.1 Uncrating

The shipping crate contains the following items:

- Electromagnetic meter assembly with grounding wire attached
- Converter cable (attached to meter)
- Signal converter
- Grounding rings
- Ground wires (2)
- User manuals for both the sensor and converter
- Installation hardware (2" & 3" only)
- Gaskets (4) (2" & 3" only)

When uncrating the Ultra Mag, any damage due to rough or improper handling should be reported to the transportation firm and McCrometer. If for any reason it is determined that the unit or parts of the unit should be returned to the factory, please contact McCrometer for clearance prior to shipment. Each unit must be properly crated to prevent any further damage. The factory assumes no responsibility for equipment damaged in return shipment due to improper packaging.

2.2 Verifying the Serial Numbers

The converter and sensor are supplied as a custom calibrated matched system. Verify the system serial numbers on both the converter and sensor match. This will ensure a properly calibrated system.

The meter serial number is located on the side of the sensor body on a silver label. An example is shown below (Figure 1).




Figure 1. Converter serial number tag

I **IMPORTANT:** Verify the meter serial numbers on both the converter and sensor match. If the meter serial numbers do not match, contact the factory before continuing with the installation.

The serial number tag is located on the side or top of the converter (Figure 2). The tag has the converter model number, the converter serial number, the meter model number and the meter serial number. Examples are shown below (Figure 3 and Figure 4).



Meter mount converter



Remote mount converter

Figure 2. Serial number tag locations for meter mount and remote mount converters



Figure 3. Serial number tag for standard model



Figure 4. Serial number tag for hazardous location model

3.0 PREPARING FOR A NEW INSTALLATION

3.1 Sensor Location

Adjoining pipe must be adequately supported, and the area around the sensor should provide sufficient drainage to prevent flooding the converter or conduits. The location chosen should provide room to read the display and be free from harsh electrical noise from adjacent equipment, cables, RFI, or EMI.

3.2 Remote Mount Converter Location

The signal converter may be installed in a desired location provided that free access is available to allow the display to be viewed as required. The unit can be either wall mounted or panel mounted with masonry fixings or nuts and bolts respectively via the fixing holes provided. The maximum distance between the meter and the converter is 25 feet. For applications with extended lengths, consult factory.

3.3 Pipe Run Requirements

The meter needs to be located a minimum distance before and after flow disturbances, such as elbows, pumps, partially opened valves, and changes in pipe diameter. The uneven flow created by these obstructions can vary with each system. The following installation recommendations should be followed (see Figure 5 for installation diagrams):

Meter size	Upstream	Downstream
2" & 3"	3D	1D
4" and above	2D	1D




Figure 5. Upstream and downstream requirements

3.4 Positioning and Orienting the Sensor

The following installation recommendations should be followed (see Figure 6 for installation diagrams):

Horizontal installation

In horizontal pipe runs, the meter should be installed so that the junction box is vertical insuring the electrodes are positioned to prevent coating by sediments or loss of electrode contact due to air bubbles.



Vertical installation

In vertical pipe runs, the flow should be upward. In slurry application, a vertical position ensures optimal distribution of solids under all flow conditions.



Less than full pipes

In pipes which may encounter less than a full pipe of fluid, the meter must be positioned in a trap to ensure that the sensor is always completely filled with liquid.




Figure 6. Sensor orientation options

4.0 FLOW METER INSTALLATION

NOTE Nothing in this manual supersedes local codes.

NOTE The flow of the medium should correspond to the direction shown by the arrow on the sensor.

4.1 Wafer Style Meter Installation

Install the Ultra Mag between two flanged end pipes. Hardware and gaskets are provided, but customers must supply the flanged pipe ends.

The flow meter may require grounding, depending on the environment they are being installed in. Refer to section 8.0 for a full description of grounding methods that are available.

4.2 Flanged Meter Installation

Install the Ultra Mag flow meter inline between two flanged end pipes. The flow meter may require grounding, depending on the environment they are being installed in. Refer to section 8.0 for a full description of grounding methods that are available.

4.3 Remote Mount Installation

You will need to prepare the location where you will install the remote converter. The location cannot be further from the flow meter than the length of the 25' cable. This must be planned in advance because **the cable cannot be lengthened**. Doing so will alter the calibration accuracy between the meter and the converter and void the warranty.

Install the flow meter as described in section 4.1 or section 4.2. Mount the converter and connect the cable to the meter's junction box and the converter's external connection. Figure 8 below shows an example of a remote mount installation with an optional Smart Output connection.




Figure 7. Wafer style meter installation




Figure 8. Example remote mount configuration

5.0 REMOTE MOUNT CONVERTER INSTALLATION

5.1 Mounting the ProComm GO Converter

Note: This applies to the remote mount converter only.

If possible, mount the converter in an electronics shed or environmental enclosure. The sun shield should be oriented in a direction to reduce sun damage and ensure readability. This electronic unit is rated IP67 for temporary flooding.

There is a stainless steel mounting plate attached to the back of the ProComm GO converter, which is used to mount the converter to a solid, flat surface using four bolts (Figure 9). Mounting plate feet are located at the top, bottom, left, and right sides.




Figure 9. Mounting converter to solid surface

5.2 Installing Cables through Cable Glands and Conduit

All electrical cables enter the converter through compression fittings or optional customer-supplied conduit located on the side or bottom of the converter (Figure 10 and Figure 11). Ensure that all compression glands are properly tightened and all unused fittings are plugged so the case remains sealed.

The power cable and wiring harnesses are each assigned specific cable glands where they will pass through into the converter. See section 5.4 for cable gland assignment for wiring harnesses and section 6.2 for wiring diagrams.

All cable compression glands must be properly tightened to prevent moisture intrusion and maintain the IP67 rating. To insure IP67 rating, use only round cable 0.24" to 0.47" in diameter.



Figure 10. Compression fittings




Figure 11. Remote mount converter with conduit pass-throughs



WARNING

Attaching conduit directly to the enclosure may introduce dangerous gasses and moisture into the enclosure creating a dangerous condition, and will remove the enclosure's IP67 rating. **Damage caused by attaching conduit to the enclosure or altering the enclosure in any way is not covered by the warranty.**



WARNING

EXPLOSION HAZARD. DO NOT REMOVE OR REPLACE LAMPS, FUSES OR PLUG-IN MODULES (AS APPLICABLE) UNLESS POWER HAS BEEN DISCONNECTED OR THE AREA IS FREE OF IGNITABLE CONCENTRATIONS.



WARNING

EXPLOSION HAZARD. DO NOT DISCONNECT WHILE THE CIRCUIT IS LIVE OR UNLESS THE AREA IS FREE OF IGNITABLE CONCENTRATIONS.



IMPORTANT: Do not cut or alter the cable length on power or signal cables!

Connections to the sensor must be made with cable supplied by McCrometer specifically for that purpose. Do not substitute the supplied cable with other types of cable, even for short runs. For repairs or added lengths of cable, the entire cable between the sensor and the converter must be replaced. (Consult factory for replacement cable.)

5.3 Pulling Sensor Cable Through Electrical Conduit

It is very important to protect the end of the sensor cable when pulling it through a conduit. Water can accumulate in low portions of conduit. Always use a cable cover, or similar method, to seal the end of the cable against water when pulling the cable through conduit (see Figure 12). This will ensure proper operation of the meter.

NOTE Cable cover is not provided.

1. Tie a rope or cable-snake securely around the middle of the cable cover.
2. Carefully pull the rope or snake until the sensor cable end clears the conduit.
3. Bring the cable end to the converter location. If necessary, secure the cable so that it does not fall back through the conduit.
4. Remove the cable cover by pulling the rip wire. The cable cover will tear off (discard the cover).

I CAUTION: Do not cut the cable cover off. Doing so may damage the sensor cable and adversely effect the calibration of the meter.




Figure 12. Cable cover

5.4 Cable Gland Assignment for Wiring Harnesses

Port assignment

- 1 - Outputs
- 2 - Outputs
- 3 - Power
- 4 - Coils
- 5 - Electrodes






Figure 13 shows the meter with three ports at the bottom labeled 1, 2, and 3. Figure 14 shows the meter with three ports at the bottom labeled 1, 2, and 3, and two additional ports on the right side labeled 4 and 5.

Figure 13. Meter mount view

Figure 14. Remote mount view

6.0 INTERNAL WIRE CONNECTION

This section describes cable and wire harness connection inside the converter. Section 7.0 describes wire connection for all peripherals outside of the converter, including pulse output and external power options.

6.1 Terminal Block Diagram and Grounding Lug




Figure 15. Terminal blocks





Figure 16. Grounding lug


6.2 Wiring Diagrams

TERMINAL BLOCK ASSIGNMENTS

Coils Harness




Terminal	Port	Wire Color
8	4	Green/Yellow
11	4	Red
14	4	Yellow




Electrodes Harness

Terminal	Port	Wire Color
1	5	Green/Yellow
2	5	Pink
3	5	Black
4	5	Blue




Pulse Output Harness

Terminal	Port	Wire Color
23	1	Pink
24	1	Brown
25	1	Yellow
26	1	Gray



4-20 mA Output Harness

Terminal	Port	Wire Color
21	1	White
22	1	Green



DC Power Harness

Terminal	Port	Wire Color
Negative	3	Black
Positive	3	Red



AC Power Harness

Terminal	Port	Wire Color
Chassis lug	3	Green
Neutral	3	White
Load	3	Black

ATTACHES TO CHASSIS LUG GREEN

To complete AC power connection, connect green grounding lug to chassis as shown on previous page.

6.3 Optional Smart Output Hook Up

The converter comes pre-wired with an interconnection that should readily connect to most AMI transceivers. Where interconnective devices are not mechanically compatible or where non-standard wiring is encountered, the installer can opt to remove the connector from the end of the converter's interface cable and make direct connection via the wiring table shown at right. (Figure 17)

- Signals and associated wire colors in the McCrometer SmartOutput™ interface cable are identified together in the top row of the table at right.
- Corresponding wire colors for transceivers from each compatible AMI vendor are identified in the columns under the top row.






	Sensus	Itron	Badger	Neptune	Elster
31	Black	Green	Black	Green	Black
32	Red	Black	Red	Black	Green
33	Green	Red	Green	Red	Red
					

Figure 17. AMI Interface Pinout

7.0 EXTERNAL WIRE CONNECTION

7.1 Cable Gland Connections

10-35VDC Power/4-20mA Output And Pulse Output

The flow meter has one dedicated port and two optional ports on the back side of the electronics enclosure. The dedicated port (center) is used to download data logger information or for meter service and troubleshooting. The two optional ports are for:

1. Optional 10-35 VDC power and 4-20mA output
2. Optional pulse outputs (flow volume and alarms)
3. AMI output
4. 100-240 VAC power

The flow meter is configured at the Factory for the optional outputs and requested by the customer at the time of order. The external cables attach through a permanent cable gland (standard, Figure 18) or through a screw locking-type waterproof connector (quick connect option, Figure 19 - see next section).




Figure 18. Standard cable gland

7.2 Quick Connect Cabled Ends (Optional)



IMPORTANT

Connections to the sensor must be made with cable supplied by McCrometer specifically for that purpose. Do not substitute the supplied cable with other types of cable, even for short runs. For repairs or added lengths of cable, the entire cable between the sensor and the converter must be replaced. (Contact factory for replacement cable.)

When quick connect cables are used both the meter and converter must have connector ports. See Figure 19 and Figure 20 for examples.

Quick Connect cable end fittings are optional. If selected at the time of order, follow the instructions below:

1. Remove the protective caps from both the receiving ports and the cable ends.
2. Insert the cable end into the port until fully seated, then turn the knurled collar on the cable to the right until the cable is tight.
3. With both cables properly attached to the meter, connect the meter-end protective cap to the cable-end protective cap. This insures that the protective caps remain free from dirt.

To remove cables:

1. Turn the knurled collar on the cable to the left until it is completely detached.
2. Replace the protective cap firmly on the connector port.



IMPORTANT

To connect sensor and converter via quick connect plugs and sockets, only use the supplied cable assemblies from McCrometer.




IMPORTANT

When not in use, always keep the attached cap firmly screwed into the connector to insure a water-tight seal. Also, keep the contacts in the cable connector clean and dry during assembly.



WARNING

EXPLOSION HAZARD. DO NOT CONNECT/DISCONNECT CONNECTORS OR WIRING OR REMOVE ENCLOSURE LID WHILE WITHIN AN ELECTRICALLY CLASSIFIED HAZARDOUS AREA.



1. Remove protective cap.
2. Insert connector into the port.
3. Turn the knurled collar on the cable until tight.
4. When cable is connected, connect the meter-end protective cap to the cable-end protective cap (not shown).

Note: Exact location of connectors may depend on converter configuration.

Figure 19. Converter optional quick connect cable ends




Figure 20. Ultra Mag junction box with optional quick connect cable ends

7.3 Power Options

Depending on output options and specific application position, you may choose to add additional power options to the battery powered converter. The 5W solar panel option (described in section 7.7) can extend battery life to 10-15 years. Additionally, you have the option of connecting external power of 10-32VDC or 100-240VAC.

7.4 DC Power Cable (Optional)

The cable contains wiring for both the optional 10-32VDC power to the meter, and the 4-20mA output from the meter. (Figure 21)

Note: Input power is for the converter only if that option was selected at time of purchase. The 4-20mA loop requires its own power supplied to the loop, not be used with red/black wires.




Figure 21. DC power cable wiring color scheme (optional)

7.5 4-20mA Current Loop

Output type: 4-20mA current loop




Figure 22. 4-20mA current loop

7.6 Pulse Output Cable (Optional)

The cable contains wiring for both pulse output 1 and pulse output 2. (Figure 23 and Figure 24)




Figure 23. Quick connect pulse output cable wiring color scheme (optional)

Figure 24. Hard wired pulse output cable wiring color scheme (optional)

7.7 Solar Panel Option



The solar panel provides power to the converter by converting sunlight into electrical energy to recharge the solar panels' rechargeable battery. Its nominal power output is 5W.

When the solar panel is installed and the cable has been run to the converter, connection inside the converter is the same as installing batteries. See Figure 25 below.


The solar panel comes complete with all accessories, except for the fixing rod.

I These instructions apply only to McCrometer-supplied solar panels with a rechargeable battery. Connecting directly to a solar panel could damage the converter.

1. Remove lid from converter base.
2. Rotate battery tray open.
3. Route solar panel output cable through the bottom left strain relief.
4. Secure strain relief on the shrink wrap (Detail A) to avoid leaks.
5. Plug solar panel output cable into battery terminal 1 (BAT1).
6. Plug triple D battery pack into battery terminal 2 (BAT2).
7. Close battery tray.




Detail A



5
BAT1

6
BAT2



Detail B




Figure 25. Solar panel electrical connection in converter

8.0 **GROUNDING AND ELECTRICAL INTERFERENCE**



NOTE: On meters installed on a line with cathodic protection it may be necessary to insulate the meter from the line. Consult your cathodic protection vendor for instructions.

Always ensure that the converter and the sensor are grounded (earthed) correctly. The grounding of the sensor and converter ensures that the equipment and liquid have an equal potential. For most installations the quality of grounding by the provided cabling assures the sensor is properly grounded and additional grounding of the sensor is not required. However, in instances where this is not the case, i.e. the equipment and fluid do not have an equal potential, such as where the installation location and/or media is subjected to electrical interference, additional grounding steps may be required. Consult an electrician experienced with instrumentation installations to determine if electrical interference is present.



Information For Grounding Ring Installations

- Gaskets must be used on either side of the grounding ring to provide a proper seal on the flanges. One gasket is used on flanges without a grounding ring.
- Rings & gaskets must align concentrically with the pipe so they do not obstruct or affect flow through the tube.
- The two grounding rings and four gaskets require an additional installation width of 0.375”.

8.1 **Sensor Grounding Methods**

All Ultra Mag flow meter installations require minimum grounding with a 12-gauge ground wire to an earth ground. Installation must conform to NEC requirements. Flanges on the Ultra Mag sensor have a non-conductive coating and may not require grounding rings. For best performance, McCrometer can provide optional grounding rings for all sizes.

When installing into a PVC or plastic pipe system, grounding rings are recommended for all sizes.

Three methods of grounding are described in this section:

- Grounding for non-conductive or internally coated pipe (preferred method of grounding)
- Grounding for meters in an electrically noisy environment
- Grounding for meters with minimal ground noise

1. Preferred method of grounding

Ultra Mag meters come standard with a set of grounding rings for use with the preferred method of grounding Ultra Mag meters.

This method can be used for all installations, but it is required for non-conductive or internally coated pipe. When pipes are non-conductive, such as PVC or internally coated pipe, you must substitute direct grounding with grounding rings. (Figure 26)

Attach the provided 12 gauge wire or equivalent to the sensor ground lug. Then connect this sensor ground lug to an earth ground point; refer to NEC or local grounding regulations for wiring requirements in making this connection.

Next, connect the two mating grounding rings with a 12 gauge wire or equivalent, attached to the grounding ring lugs, and connect them both to the earth ground. The Ultra Mag should be electrically isolated from the pipeline.




Figure 26. Preferred method of grounding

2. Sensor grounding for meters in an electrically noisy environment

If there is electrical noise in the fluid column or electrical current in the pipe, it can be minimized or eliminated using grounding rings or by grounding the pipeline. This applies to meters mated to conductive uncoated pipe.

Attach the provided 12 gauge wire, or equivalent, to the ground lug. Then connect the sensor ground lug to an earth ground point. (Figure 27)

Next, connect the two mating pipe sections with a 12 gauge wire or equivalent and connect them both to the earth ground. The Ultra Mag should be electrically isolated from the pipeline.




Figure 27. Sensor grounding for meters in an electrically noisy environment

3. Sensor grounding for meters with minimal ground noise

Attach the provided 12 gauge wire, or equivalent, to the sensor ground lug. Then connect this sensor ground lug to an earth ground point. (Figure 28)




Figure 28. Sensor grounding for meters with minimal ground noise

9.0 BATTERY REMOVAL AND REPLACEMENT

This procedure applies to all flow meters with the ProComm GO converter. It describes how to install batteries in a new meter and how to replace batteries using the replacement battery kit PGK01.











WARNING

EXPLOSION HAZARD. DO NOT DISCONNECT WHILE THE CIRCUIT IS LIVE OR UNLESS THE AREA IS FREE OF IGNITABLE CONCENTRATIONS.

Before you begin:


Check materials and tools to ensure you have everything you need.

Materials Provided (shown in order of use)

<p>One triple D battery pack</p> 	<p>One double A battery pack</p> 	<p>Replacement cover gasket</p> 	<p>Molykote lubricant</p> 
<p>Zip ties: • 2 large • 1 small</p> 	<p>Dry pack</p> 	<p>Tamper proof wire seal</p> 	<p>Tool Required</p> <p>Wire cutters Phillips screwdriver 5/32" Allen driver</p> 

I. Removing the cover

1. Cut off the tamper-proof seal and remove the wire from the security screw.
NOTE: This step is not required for battery installation in new meters.
2. Remove screws holding the lid to the housing using a 5/32" Allen driver. Lift the lid up and place the lid upside hanging by the green ground wire.




If you are replacing batteries with fresh batteries, continue to step 3.

If you are installing batteries in a new meter that does not have batteries already installed, go to step 9.


II. Removing the batteries

- Unplug tall connectors to sensor, outputs, and power.




Connectors


- Loosen the captive screws opposite of the hinge and lift the battery cover.



- Unplug the batteries.



- Cut the two zip ties securing the batteries.




Zip ties

- Remove the large battery pack.



Large battery pack


- Remove the small battery pack located underneath. Pull the wires carefully from underneath the battery tray.




Small battery pack

III. Installing the batteries and restoring the power

9. Cut the zip tie holding the dry pack to the hinge on the converter base.




10. Pass the new zip tie through the slots in the internal hinge.



11. Wrap the new zip tie around the new dry pack and cut off the excess.




12. Pass the two large zip ties through the slots in the internal tray holder.



13. Place the small battery pack in the center pocket, making sure the wire leads go out through the opening.



14. Place the large battery pack on the internal tray with wire leads passing through the slot.




15. Secure the battery packs to the internal tray with the two large zip ties. Cut off the excess of each of the zip ties.




16. Plug the batteries into the circuit board.


- The large battery pack goes to connector B1.
- The small battery pack goes to connector B2.



17. Set the hinged LCD/internal battery cover back in place to see the display. The unit will start to power up. Plug in all of the connectors to the board. Ensure that the unit is powered normally and there are no alarms.



18. Replace the two screws that hold the LCD/battery cover in place.




IV. Replacing the gasket


If you installed replacement batteries, we recommend that you replace the gasket.

If you installed new batteries, you must set the gasket in place before replacing the cover and closing up the unit.

19. If your unit has a gasket, remove it.



20. Apply a light coating of Molykote to the replacement gasket.



21. Place the gasket in the groove and press it in.




V. Replacing the cover


22. Place the converter lid onto the housing. Tighten the screws firmly. Be careful not to pinch any wires between the lid and the base.



23. Fasten the tamper proof seal as follows:
 a. Guide the wire through the hole in the screw.
 b. Thread the wire through the body of the tamper proof seal.



24. Rotate the blue part on the tamper proof seal to bring in the wire and secure the seal close to the screw.



10.0 OPERATION

10.1 General

The flow meter comes pre-configured from the factory based on the installation parameters provided to McCrometer at the time of order. Other than activating the display, there is nothing required of the user for the basic operation of the flow meter.

10.2 Activating the Display

The display is activated when the lid is opened. (Figure 29) The display will remain active for 30 seconds.

The various parts of the interface screen is shown below. (Figure 30) Depending on how the converter is configured with the configuration tool (see section 11.0) the display will show either single direction or bidirectional total flow quantities. Bidirectional flows are represented as either positive (POS) or negative (NEG), as shown at right.



Figure 29. Lift lid to activate display



CAUTION:

If the lid is broken off, contact the Factory for a lid replacement kit. In the meantime, set the lid on the meter in its proper position and use the boot to hold it in place.



The converter display is light activated and requires a minimum amount of light to appear. Environments where light is low, such as in dimly lit buildings or outdoors after sundown may prevent the display from appearing when the lid is raised.

There is an optical sensor embedded in the display located under the McCrometer "swirl" logo at the lower left. If the display does not appear, a flashlight will provide sufficient light to bring it up.




Figure 30. Interface screen, bidirectional and single direction flow

10.3 Converter Boot

The boot simply slips over the electronics enclosure. When installing the boot, insure the corners of the boot fit snugly over the lip of the enclosure. See Figure 31. To remove the boot, grip two corners and pull them away from the lip of the enclosure and then pull upwards. See Figure 32.



It is **HIGHLY** recommended that converter is covered by the boot at all times when the meter is not being read. The boot adds protection to the converter.




Figure 31. Boot installation





Figure 32. Boot removal

11.0 CONVERTER CONFIGURATION

The converter can be programmed to customize how the data is measured and stored. The configuration tool runs only on Windows 7, 8, or 10 and requires a computer with a USB port.

To access the converter's USB port, unscrew the cap at the left side of the converter. You will need a cable with a mini USB type B connector. (Figure 33)



WARNING
EXPLOSION HAZARD. DO NOT CONNECT/DISCONNECT CONNECTORS OR WIRING OR REMOVE ENCLOSURE LID WHILE WITHIN AN ELECTRICALLY CLASSIFIED HAZARDOUS AREA.

You must have your flow meter's serial number before you begin. There are no installation files. The program and support files can be copied or unzipped into a folder and run from there.

This is only a summary of the configuration tool's functionality. The software has complete set-up and operation instructions included. The software can be downloaded from the McCrometer Web site.

Software Operation

1. Remove the cap that protects the USB port and plug in a mini USB type B cable. (Figure 34) Connect the other end to a laptop computer.
2. Start the software. Follow the instructions shown before setting up your customized configuration. (Figure 35)
3. When you have set up your configuration file, you can change the settings listed below. Using the configuration tool is mostly self-explanatory.
 - Flow rate unit of measure
 - Totalizer unit of measure
 - Multiplier
 - Totalizer presets
 - Forward/reverse pulse enable: 1 pulse per x per unit of measure
 - Pipe ID
 - Clock time and date
 - Pulse output
 - Automated meter reading

When configuration is complete, remove the USB connector and replace the protective cap.



Figure 33. Mini USB type B connector



Figure 34. Plug in mini-USB cable





Figure 35. Configuration tool interface

12.0 ERROR MESSAGES FOR TROUBLESHOOTING

DISPLAY MESSAGE	Troubleshooting
BAT LOW	Battery replacement Kit is needed to replace batteries. The batteries Should last approximately 6-9 months from the time the warning is shown.
420 ERR	The 4-20 circuit is not wired correctly. Check the wiring diagram and ensure 9-30VDC power is supplied to the circuit. The output is not source powered.
COIL XCT	There is an issue with the electro magnetic coils. Check that the internal wiring is correct in the converter for the coil wires.
ADC CLIP	The meter signal exceeds the limit of the converter, likely due to noise. Check the meter grounding meets the IOM guidelines and identify any sources of noise.
HIGH HUM	Humidity inside converter housing has exceeded limits. Check for any loose connections on converter housing that could be creating a leak.
COIN LOW	Datalogger time backup battery is low. This is part of the battery replacement kit and should be replaced with the main battery packs.

13.0 REPLACEMENT PARTS



The image above is representative for all Ultra Mag meter models and sizes.

NO.	PART NUMBER	DESCRIPTION
1	PC-RA1	AC Converter (Dual 4-20mA Output)
1	PC-RD1	DC Converter (Dual 4-20mA Output)
1	PC-RA2	AC Converter w/ Modbus RS485 Communications Protocol
1	PC-RD2	DC Converter w/ Modbus RS485 Communications Protocol
2	15035 / 15036	Dual Cables - Submersible
3	1-1557-*	Gaskets (Optional)
4	3-2781-*	Grounding Rings, Stainless Steel (Optional on 4"-12")
5	3-2757-##	Grounding Wire Assembly
6	1-1201-10	Nut, Hex, Brass
7	15029	Earth Ground Wire

* INSERT METER SIZE TO COMPLETE PART NUMBER - INSERT -02 FOR 2", -04 FOR 4", -06 FOR 6", ETC.
 ## -W = 2" - 16" -14 = 14" - 20" -24 = 24" - 30" -36 = 36" - 48"




When ordering replacement parts, please specify: Meter Size • Meter Model • Meter Serial Number

14.0 SPECIFICATIONS, WEIGHTS, AND DIMENSIONS

14.1 Flow Meter Specifications

Pipe Sizes	
	2", 3", 4", 6", 8", 10", 12", 14", 16", 18", 20", 24", 30", 36", 42", 48"
Flow Direction Measurement	
	Forward and reverse flow indication and forward, reverse, net totalization are standard with all meters
Accuracy	
	<ul style="list-style-type: none"> Standard: +/- 0.5% of measured value ± 0.006 ft/s (± 0.0018 m/s) Optional: +/- 0.2% of measured value ± 0.006 ft/s (± 0.0018 m/s) Battery powered: 1% of measured value ± 0.006 ft/s (± 0.0018 m/s) <p>IMPORTANT NOTICE ON FLOW METER ACCURACY: The flow meter, the cable and the electronics are factory calibrated for accuracy as a single unit. Changing the cable length with the Splice Kit changes the accuracy of the meter and invalidates the calibration certificate.</p>
Accuracy Tests	
	Multiple point wet flow calibration of every complete flow tube with its signal converter. If desired, the tests can be witnessed by the customer. The McCrometer test facilities are traceable to the National Institute of Standards & Technology. Uncertainty relative to flow is $\pm 0.15\%$.
Pipe Run Requirements	
2" & 3" wafer style	3D upstream / 1D downstream
4" and larger flanged	1D upstream / 0D downstream
Repeatability	
	$\pm 0.05\%$ or ± 0.0008 ft/s (± 0.25 mm/s), whichever is greater
Conductivity	
	5 μ s/cm
Liner	
	UltraLiner NSF approved, fusion bonded epoxy
Electrodes	
	Type 316 stainless steel, others optional
Electrical Connections	
	<ul style="list-style-type: none"> Compression gland seals Quick-Connect
Sensor Cable Lengths	
Standard	25'/7.6 m McCrometer supplied submersible cable with each remote mount unit.
Optional	Up to 500'/152.4 m, or 25'/7.6 m max for battery powered.
Quick Connect	Available in standard cable lengths: Feet: 25, 50, 75, 100, 125, 150, 175, 200, 500 Meters: 7.6, 15.25, 22.5, 30.5, 38.1, 45.75, 53.3, 61, 152.4 Custom cable lengths at additional cost.

Flow Meter Specifications (cont.)

IP Rating	
Standard model	<ul style="list-style-type: none"> • Quick Connect (NEMA 6P/IP68 with remote converter) • Compression gland seals (NEMA 6P/IP68 with remote converter)
HL model	<ul style="list-style-type: none"> • Quick Connect (IP67) • Compression gland seals (IP67)
Sensor Submersibility Depth	
With standard strain relief cable	9 m (30 ft.)
With optional quick connect cable	1.8 m (6 ft.)
Head Loss	
	None. No obstruction in line and no moving parts
Warranty	
Meter	2 year warranty
Liner	Lifetime guarantee
Pressure Range	
	AWWA Class D (150 psi Rating) (Standard) ANSI Class 150# (285 psi Rating) ANSI Class 300# (300 psi Rating) AWWA Class F (300 psi Rating)
Velocity Range	
	.2 to 32 FPS
Temperature Range	
	Sensor Operating: -10 to 60°C (14 to 140°F) Sensor Storage: -15 to 60°C (5 to 140° F)
Certifications and Approvals	
Standard Model	<ul style="list-style-type: none"> • ISO 9001:2015 certified quality management system • Certified by MET to UL 61010-1 / CSA C22.2 No. 61010-1 • Certified to NSF / ANSI Standards*
HL Model	<ul style="list-style-type: none"> • ISO 9001:2015 certified quality management system • Certified by MET: Safety: UL61010-1 / CSA C22.2 No. 61010-1, Third Edition: Safety of Electrical Equipment For Measurement, Control, and Laboratory Use • Certified by MET: Standards: ANSI / ISA12.12.01 / CSA C22.2 No. 213, Nonincendive Electrical Equipment <ul style="list-style-type: none"> • Class I and II, Division 2 • Class III, Divisions 1 and 2 Hazardous (Classified) Locations • Certified to NSF / ANSI Standards*
	  
System Options	
	<ul style="list-style-type: none"> • Hastelloy® electrodes • Additional sensor cable up to 475' • Annual verification / calibration • Stainless steel ID tag

* Ultra Mag is certified by IAPMO R&T to NSF/ANSI 61 for material safety and NSF/ANSI 372 for low lead content.

Flow Meter Specifications (cont.)

Meter Options

- | | |
|--|---|
| <ul style="list-style-type: none">• DC powered converter (10-35 VDC, 21 W)• Meter mounted converter• Extended warranty• Hastelloy® electrodes• ANSI or DIN flanges• Special lay lengths, including ISO standard lay lengths | <ul style="list-style-type: none">• Quick Connect cable fittings• Converter sun shield• HART® Converter• Smart Output™ (Sensus or Itron compatible)• Battery or battery-solar powered converter |
|--|---|


14.2 Flow Meter Dimensions and Weights

2" and 3" Models Body Style

Use model shown below for dimensions.

Meter Type	Pipe Size (Nominal)	Meter Pipe ID	Flow Ranges GPM Standard .2 to 32 FPS Min - Max	DIMENSIONS (Lay Lengths)								Est. Shipping Weight (lbs.)*		
				A		B	C		D		E		CL150 AWWA Class D	CL300 ANSI #300
				CL150 AWWA Class D	CL300 ANSI #300		CL150 AWWA Class D	CL300 ANSI #300	CL150 AWWA Class D	CL300 ANSI #300	CL150 AWWA Class D	CL300 ANSI #300		
Wafer style	2"	1.625	2 - 310	11	14	4.5	6.0	6.5	6.5	7.25	3.15	4.69	9.6	10.1
	3"	2.625	5 - 700	13.4	15.5	4.5	7.5	8.25	7.0	7.75	4.35	5.44	11.3	11.8

* For remote mount meters, add 4 lbs for ProComm converter.




Grounding rings are 0.0625" thick.

4" to 12" Models Body Style

Pipe Size (Nominal)	Meter Pipe ID		Flow Ranges GPM Standard .2 to 32 FPS Min - Max	DIMENSIONS (Lay Lengths)					Est. Shipping Weight (lbs.)*	
	CL150 AWWA Class D	CL300 ANSI #300		A		B		C	CL150 AWWA Class D	CL300 ANSI #300
				CL150 AWWA Class D	CL300 ANSI #300	CL150 AWWA Class D	CL300 ANSI #300			
4"	3.834	3.76	8 - 1,140	13.40	13.40	9.00	10.00	7.28	78	108
6"	5.782	5.732	19 - 2,660	14.60	14.60	11.00	12.50	8.25	82	138
8"	7.782	7.732	33 - 4,870	16.10	17.25	13.50	15.00	9.25	115	195
10"	9.782	9.732	52 - 7,670	18.50	18.50	16.00	17.50	10.5	144	247
12"	11.782	11.732	74 - 11,180	19.70	19.70	19.00	20.50	11.5	193	342


* For remote mount meters, add 4 lbs for ProComm converter.



14+\" Models Body Style

Pipe Size (Nominal)	Meter Pipe ID	Flow Ranges GPM Standard .2 to 32 FPS Min - Max	DIMENSIONS (Lay Lengths)							Est. Shipping Weight (lbs.)*	
			A		B	C		D	E	CL150 AWWA Class D	CL300 ANSI #300
			CL150 AWWA Class D	CL300 ANSI #300		CL150 AWWA Class D	CL300 ANSI #300				
14"	13.63	90 - 16,070	21.70	22.75	11.875	21.00	23.00	20.135	14.56	321	476
16"	15.50	118 - 20,900	23.60	25.25	14.25	23.50	25.50	21.635	15.32	390	645
18"	17.50	150 - 26,480	23.60	25.25	14.25	25.00	28.00	23.635	16.32	446	750
20"	19.50	185 - 32,720	25.60	28.25	16.06	27.50	30.50	25.6975	17.35	588	874
24"	23.50	270 - 47,180	30.70	35.75	21.75	32.00	36.00	29.51	19.25	769	1,568
30"	29.25	420 - 73,620	35.80	41.75	25.25	38.75	43.00	35.6975	22.35	1,261	2,317
36"	35.25	610 - 105,930	46.10	46.10	28.63	46.00	50.00	42.76	25.88	1,696	2,915
42"	41.25	830 - 144,370	48.05	***	36.25	52.75	***	48.135	28.57	***	***
48"	47.25	1,080 - 188,430	50.00	***	36.25	59.50	***	54.135	31.57	***	***

* For remote mount meters, add 4 lbs for ProComm converter.



14.3 ProComm GO Converter Specifications

Physical Specifications

Electronic Housing	Diecast aluminum, powder coated enclosure w/ tamper resistant seal, 6½" x 6½" x 43/8" tall
Converter Dimensions	See "Dimensions" section for meter mount and remote mount converter dimensions.
Power	Battery: Standard: three 3.6V lithium-thionyl chloride (Li-SOCl ₂) D size batteries with two AA backup batteries AC Power: 100-240VAC/45-66Hz (4W) DC Power: Linear power supply 10-35VDC (4 W)
Electrical Connections	<ul style="list-style-type: none"> • Optional shielded cable for 10-32VDC/4-20 mA output • Optional shielded cable for pulse out

Performance and Operational Specifications

Battery Life	Five-year expected battery life, five-year battery warranty
Location	Indoor or outdoor use
Altitude	Operating: 2000 meters Storage: 12,000 meters
Operating Temperature	-4° to 140° F (-20° to 60° C)
Storage Temperature	-4° to 140° F (-20° to 60° C)
Relative Humidity	0% to 100%
IP Rating	IP67 Die cast aluminum converter
Outputs	Digital output: Digital pulse (open collector) output for volumetric - Two isolated digital pulse (open collector) outputs for volumetric - AMI output Analog output: 4-20mA: Galvanically Isolated, 16 Bit resolution. All power configurations (including battery). Note: 9-30 VDC loop power required (not supplied via converter)

Display and Measurement

Display	<ul style="list-style-type: none"> • 2-Line LCD display (no backlight) • Non-volatile memory • Anti-reverse totalizer (standard) • Total (to 9 digits of precision) 	<ul style="list-style-type: none"> • Flow rate and velocity (to 5 digits of precision) • Two alarms: low battery and empty pipe (optional) • Opening lid activates display
Digits	5 Rate, 9 Total	
Units	GPM Gallons per minute IGM Imperial gal per minute CFM Cubic feet per minute MGD Mega gal per day MI9 Miners inch (9G) B5M Barrels per minute (55G) CFS Cubic feet per second MI1 Miners inch (11.22G) B5H Barrels per hour (55G) MLD Megaliters per day APD Acre feet per day B5D Barrels per day (55G) LPS Liters per second KLH Kiloliters per hour B4M Barrels per minute (42G) CMH Cubic meters per hour LPH Liters per hour B4H Barrels per hour (42G) LPM Liters per minute CMM Cubic meters per minute B4D Barrels per day (42G) GPH Gallons per hour CFM Cubic feet per minute	



SPECIFICATIONS, WEIGHTS, AND DIMENSIONS

Totalizer Units	GAL	Gallons	B42	Barrel (42G)	MH1	Miners Inch Hour (11.22G)
	CUF	Cubic Feet	B46	Barrel (46G)	MD1	Miners Inch Day (11.22G)
	AFT	Acre Feet	B55	Barrel (55G)	MH9	Miners Inch Hour (9G)
	CUM	Cubic Meters	IMG	Imperial Gallon	MD9	Miners Inch Day (9G)
	LIT	Liters	AIN	Acre Inch	KGL	Kilo Gallons
	MML	Megaliter	TON	Ton (Short)	MGL	Mega Gallons
	MTT	Metric Ton (KL)	MM1	Miners Inch Minute (11.22G)	IN3	Cubic Inch
	B31	Barrel (31G)	MM9	Miners Inch Minute (9G)		
	Data Logger	Standard with all models, minimum of five years of data stored				

Other Specifications

Options and Accessories

- Data Logger - included as standard with five years of data storage at default (12hr) interval. (Cable sold separately)
- AC, DC, and battery powered with battery backup powered available

Safety

- IEC 61010-1, Pollution Degree II
- Overvoltage protection Category III

Certifications

Standard Model




- ISO 9001:2015 certified quality management system
- Certified by MET to UL 61010-1 / CSA C22.2 No. 61010-1

HL Model



- ISO 9001:2015 certified quality management system
- Certified by MET: Safety: UL61010-1 / CSA C22.2 No. 61010-1, Third Edition: Safety of Electrical Equipment For Measurement, Control, and Laboratory Use
- Certified by MET: Standards: ANSI / ISA12.12.01 / CSA C22.2 No. 213, Nonincendive Electrical Equipment
 - Class I and II, Division 2
 - Class III, Divisions 1 and 2 Hazardous (Classified) Locations



14.4 ProComm GO Converter Dimensions



Remote mount converter



15.0 RETURNING A UNIT FOR REPAIR

If the unit needs to be returned to the factory for repair, please do the following:

- Prior to calling for a return authorization number, determine the model number, serial number, and reason for return.
- Contact McCrometer Customer Service Department and ask for a Return Authorization (RA) number.
 - Telephone: 1-800-220-2279
 - Email: customerservice@mccrometer.com
- Ship the meter in the original packaging, if possible. Do not ship manuals, power cords, or other parts with your unit unless required for repair.
- Please make sure the meter is clean and free from foreign debris prior to shipping. McCrometer may charge a cleaning fee if the meter is sent without being cleaned.
- Write the RA number on the outside of the shipping box. All return shipments should be insured.
- Address all shipments to:

McCrometer, Inc.
RMA #
3255 W. Stetson Avenue
Hemet, CA 92545

WARRANTY

This Warranty shall apply to and be limited to the original purchaser consumer of any McCrometer product. Meters or instruments defective because of faulty material or workmanship will be repaired or replaced, at the option of McCrometer, free of charge, FOB the factory in Hemet, California, within a period of two (2) years from the date of delivery.

Repairs or modifications by others than McCrometer or their authorized representatives shall render this Warranty null and void in the event that factory examination reveals that such repair or modification was detrimental to the meter or instrument. Any deviations from the factory calibration require notification in writing to McCrometer of such recalibrations or this Warranty shall be voided.

In case of a claim under this Warranty, the claimant is instructed to contact McCrometer Inc., Attn: Technical Support, 3255 W. Stetson Ave., Hemet, California 92545, and to provide an identification or description of the meter or instrument, the date of delivery, and the nature of the problem.

The Warranty provided above is the only Warranty made by McCrometer with respect to its products or any parts thereof and is made expressly in lieu of any other warranties, by course of dealing, usages of trade or otherwise, expressed or implied, including but not limited to any implied warranties of fitness for any particular purpose or of merchantability under the uniform commercial code. It is agreed this Warranty is in lieu of and buyer hereby waives all other warranties, guarantees or liabilities arising by law or otherwise. Seller shall not incur any other obligations or liabilities or be liable to buyer, or any customer of buyer for any anticipated or lost profits, incidental or consequential damages, or any other losses or expenses incurred by reason of the purchase, installation, repair, use or misuse by buyer or third parties of its products (including any parts repaired or replaced); and seller does not authorize any person to assume for seller any other liability in connection with the products or parts thereof. This Warranty cannot be extended, altered or varied except by a written instrument signed by seller and buyer.

This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

McCrometer reserves the right to make improvements and repairs on product components which are beyond the Warranty period at the manufacturer's option and expense, without obligation to renew the expired Warranty on the components or on the entire unit. Due to the rapid advancement of meter design technology, McCrometer reserves the right to make improvements in design and material without prior notice to the trade.

All sales and all agreements in relation to sales shall be deemed made at the manufacturer's place of business in Hemet, California and any dispute arising from any sale or agreement shall be interpreted under the laws of the State of California.

OTHER McCROMETER PRODUCTS INCLUDE:

Propeller Flow Meters



Differential Pressure Flow Meters



Magnetic Flow Meters



Connected Solutions



Copyright © 2022 McCrometer, Inc. All printed material should not be changed or altered without permission of McCrometer. Any published pricing, technical data, and instructions are subject to change without notice. Contact your McCrometer representative for current pricing, technical data, and instructions.

3255 WEST STETSON AVENUE • HEMET, CALIFORNIA 92545 USA
TEL: 951-652-6811 • 800-220-2279 • FAX: 951-652-3078
www.mccrometer.com

