the pro+fit[™] installation system



The Pro+Fit[™] System eliminates set-screws for faster, more durable mounting. There's even a template with a built-in level.

Moen's patented 3-step Pro+Fit[™] installation system is the most innovative, simple way to mount bath accessories. Pro+Fit[™] reduces installation time to one-third that of standard bath accessories. Installation is as easy as 1-2-3.

- 1. **Drilllt:** Use the installation mounting template with built-in level.
- 2. Screwit: Screw in the pre-attached fastener.
- 3. **Click It:** Press on the post until it locks into place.

It really is that simple! Plus, we've eliminated the set screw.

Designed with input from professional installers, the Pro+Fit[™] Installation System was made for faster installation and fewer call backs. And of course, there's the extra assurance of quality that comes with the Moen brand.

Available on Brantford[™], Eva[™], Icon[™] and Mason[®] collections by Moen[®].





YB8080

Pro+Fit[™]

Install Template

DRILL IT!



The innovative template has a built-in level for accurate drilling of pilot holes for both 18" and 24" towel bars or paper holders.

SCREW IT!



Single screw mounting system uses pre-attached hollow wall anchor for a fast solid installation.



CLICK IT!



Locking tab clicks to hold the post firmly in place and eliminates the need for a set screw.



Brantford[™]



(BN) Brushed Nickel (CH) Chrome (ORB) Oil Rubbed Bronze





(BN) Brushed Nickel (CH) Chrome (ORB) Oil Rubbed Bronze



(BB) Brushed Bronze

(BN) Brushed Nickel

> (CH) Chrome

Mason®



(BC) Brushed Chrome (CH) Chrome (CP) Chrome & Polished Brass (OWB) Old World Bronze (PB) Polished Brass (SN) Satin Nickel