

# TEXTURE PRODUCTS (NON-AGGREGATED)

## PROFORM® BRAND ALL PURPOSE READY MIX ■ MULTI-USE ■ TOPPING



### GENERAL INFORMATION

ProForm All Purpose Ready Mix, Multi-Use and Topping is primarily used in manufactured housing for texturing walls and/or ceilings when a “stomp or knockdown” look is desired. They can also be used for complete joint finishing of gypsum wallboard applied to walls.

Due to the manufactured housing industry’s need for extra joint strength and timed drying, these products are not usually recommended for use on ceilings.

### FEATURES/BENEFITS

- Ready to use.
- Excellent adhesion/bond.
- Versatile.

### SPECIFICATIONS

#### Sizes:

- Multi-Use**  
4.5 gal. (17L) pail  
4.5 gal. (17L) carton  
3.5 gal. (13L) carton

#### Topping

- 50 lb. (22.7 kg) carton  
61.7 lb. (28 kg) pail

#### All Purpose

- 48 lb. (21.7 kg) carton  
50 lb. (22.7 kg) carton  
61.7 lb. (28 kg) pail  
61.7 lb. (28 kg) carton

### SPECIFICATIONS

If ProForm Ready Mix product freezes, allow material to thaw at room temperature for at least 24 hours. When thawed, turn the container upside-down for at least 15 minutes. Turn pail right side up, remove lid, and immediately remix with an electric drill. ProForm Ready Mix products should be lump-free and ready to use within 1 minute. Discard all ProForm Ready Mix products that do not remix to a lump-free consistency.

### GENERAL APPLICATION

Temperatures should be maintained at a minimum 50°F (10°C), both day and night, before and during spray operations and until sprayed surfaces have fully dried.

Adequate ventilation should be provided to eliminate excess moisture in the spray booth, will aid in drying and will help prevent many problems associated with slow drying of water-based texture products. Use of a respirator and eye protection is recommended during spray application.

Gypsum wallboard: Surfaces, including joint treated areas, must be smooth, clean and dry. First, apply a coat of good quality primer. Mask appropriate areas before spraying, and promptly remove overspray from unprotected surfaces afterward. Follow the instructions of the spray equipment manufacturer for adjusting controls and cleaning. If a second coat is desired, allow the first coat to dry completely. Surface then must be painted after texture is dry.

ProForm Ready Mix products may be hand-applied to the ceiling from a flat surface or may be thinned slightly with water and spray-applied.

If spray application is chosen, adequate equipment should be used and adequate control of air pressure should be available. By adjusting mixture consistency and/or varying the air pressure, ProForm Ready Mix creates an almost endless variety of textures, the most typical of which are Spray Spatter, Spatter Knock-Down and Orange Peel.

**Caution:** Avoid creating dust. When mixing, ventilate area, wear eye protection and a NIOSH- or MSHA-approved respirator for dust.

ProForm Ready Mix products are not considered a finished surface, but need no further preparation in order to be painted.