

# HENRY®



## 545

**Fast-setting, feather edge patch and underlayment**

### Versatile

Use for most subfloor prep needs

### Fast-setting

Ready for most flooring in 1-2 hours

**Good Fill Characteristics**  
Featheredge to 1/2" using two 1/4" applications

### Non-sanded Formulation

Trowels easily to a smooth finish

### Non-shrinking

Reduces installation time

### Use On Most Substrates

Includes "cutback" residue

### High Compressive Strength

Exceeds 4200 psi

### Size Available

25 lb. bag

**THE PROFESSIONAL'S FORMULA FOR SUCCESS™**

# HENRY® 545

**HENRY 545 Feather Edge Cement Patch is The Professional's Formula For Success™ when patching and leveling subfloors. Can be used on concrete, wood, and over existing "cutback" residue.**

SUBSTRATE	CEMENT-BASED PATCHES & UNDERLAYMENTS	
	HENRY 445	HENRY 545
	FAST-SETTING FLOORING UNDERLAYMENT	FEATHER EDGE CEMENT PATCH
	Fast Dry	Fast Dry, Feather Edge
Commercial Applications	BETTER	BETTER
Residential Applications	BETTER	BEST
Patch holes and voids in wood	BETTER	BEST
Skim-coat wood underlayments		BEST
Underlayment joints	BETTER	BETTER
Patch concrete on or above grade only	BETTER	BETTER
Patch concrete on all grade levels	BETTER	BETTER
Existing asphalt "cutback" adhesive residue on concrete		BETTER
Ceramic, terrazzo and marble	BETTER	BETTER
Polymeric poured floor	BETTER	BETTER

#### INSTALLATION TIPS:

- Condition the area to be installed, adhesive, underlayment, and flooring to 65°F (18°C) or above for 48 hours before, during, and for 48 hours after installation. Maximum temperature for use is 90°F.
- Subfloor must be smooth, sound, dry, clean, and free of dirt, wax, polish, paint, and all other foreign matter which may interfere with a good bond including curing agents and sealers. Concrete must be dry and free of excess alkali.
- Slightly dampen concrete substrates with clean water and apply underlayment while damp. Do not leave standing water.
- For a superior bond, prime wood with HENRY 546 Feather Edge Additive.
- "Cutback" adhesive residue must be covered completely to prevent bleeding through the new flooring.
- Can be applied in one layer featheredged to 1/4" thick or two layers up to a maximum thickness of 1/2".
- To mix a whole bag, add 25 lbs. of powder to 1 gallon water. For smaller batches, mix 3 parts powder to 1 part water (by volume). Working time can be extended by mixing the powder with water and HENRY 546 Feather Edge Additive at a 50/50 ratio.
- Mixing containers must be clean as unused material will contaminate newly mixed underlayment.
- Do not add additional water after the proper consistency has been reached. If underlayment starts to set before using, discard and do not attempt to remix.
- Use the flat side of a steel trowel to patch and level.
- Do not over-trowel or re-trowel.
- Clean tools with water frequently and dip trowel in water often to make finishing easier.
- All finishing must be done within 10 to 15 minutes when patching or leveling.
- As a patch or leveler, allow to dry for 30 minutes to 2 hours before installing floor covering.
- Clean all tools with water before the material dries.
- Most adhesives will exhibit shorter working times when used over HENRY 545.

#### SUBSTRATES:

**HENRY 545 Feather Edge Cement Patch** will bond to the substrates listed.

Specific installation recommendations should come from the flooring manufacturer:

- Interior concrete only
- Wood and wood underlayments; wood should be suspended; not for stripwood floors
- Ceramic tile, terrazzo (except metal terrazzo strips), marble, and polymeric poured floors
- Existing asphalt "cutback" adhesive residue which is smooth with no ridges or puddles evident
- Primed, poured-in-place gypsum subfloors
- Radiant heated subfloors where the surface temperature does not exceed 85°F (29°C)

# HENRY®

The W.W. Henry Company  
400 ARDEX Park Drive  
Aliquippa, PA 15001  
(724) 203-8000

Customer Service and Technical Information  
1-800-232-4832  
www.wwhenry.com

#### HENRY Commitment

HENRY is committed to helping you get the best results in professionally installed floors. 70 years of experience combined with our relationships with the leading resilient, wood and carpet manufacturers ensure that you receive the products and the support you need to complete the job successfully and profitably.

HS101 (Rev. A 06/05)

# THE PROFESSIONAL'S FORMULA FOR SUCCESS™