

HENRY®



546

Increases applications for
HENRY 545 and HENRY 547
underlayments

Improves Bond

For recommended substrates

Enhances Flexural Strength

Over wood, metal and existing floors

Fast-Setting

Shortens dry time of HENRY 545
and HENRY 547

Extends Pot Life

For added working time

AGIS Guarantee

Included as part of Armstrong
Guaranteed Installation System
when used with HENRY 547
and Armstrong flooring

Sizes Available

1 gallon, 4 gallon



THE PROFESSIONAL'S FORMULA FOR SUCCESS™

HENRY[®] 546

HENRY 546 is The Professional's Formula For Success when used with HENRY 545 and HENRY 547 subfloor preparation products.

SUBSTRATE	PRIMERS & ADDITIVES	
	HENRY 336	HENRY 546
	FLOOR PRIMER & ADDITIVE	FEATHER EDGE ADDITIVE
	As An Additive w/HENRY 331	As An Additive w/HENRY 545 & 547
Commercial Applications		OPTIONAL
Residential Applications	OPTIONAL	OPTIONAL
Patch holes and voids in wood	OPTIONAL	OPTIONAL
Skim-coat wood underlayments		REQUIRED
Underlayment joints		REQUIRED
Patch concrete on or above grade only	OPTIONAL	OPTIONAL
Patch concrete on all grade levels		OPTIONAL
Ceramic, terrazzo and marble		OPTIONAL
Polymeric poured floor		OPTIONAL
Steel		REQUIRED
Stainless Steel		REQUIRED
Lead		REQUIRED
Embossing Leveler		
Residential floor with stain-resistant wear layer		REQUIRED
Residential floor without stain-resistant wear layer		REQUIRED

SUBSTRATES:

HENRY 546 Feather Edge Additive will bond to the substrates listed. Specific installation recommendations should come from the flooring manufacturer:

- Concrete
- Primed, poured-in-place gypsum subfloors
- Wood and wood underlayments

INSTALLATION TIPS:

- Condition the area to be installed, adhesive, underlayment, latex, and flooring to 65°F (18°C) or above for 48 hours before, during, and for 48 hours after installation.
- Subfloor must be smooth, sound, dry, clean, and free of dirt, wax, polish, paint, and all other foreign matter which may interfere with a good bond including curing agents and sealers. Concrete must be dry and free of excess alkali.
- Apply with a short nap paint roller or a coarse fiber brush. Do not allow puddles to form or remain on the surface.
- Use full strength.
- Allow to dry completely, approximately 30 minutes or more.
- Clean tools with water before material dries.

HENRY

The W. W. Henry Company
 400 Ardex Park Drive
 Aliquippa, PA 15001
 Technical Support: 1-800-232-4832
 Internet: wwhenry.com

IPD-241-899

HENRY Commitment

HENRY is committed to helping you get the best results in professionally installed floors. Sixty years of experience combined with our relationships with the leading resilient, wood and carpet manufacturers ensure that you receive the products and the support you need to complete the job successfully and profitably.

THE PROFESSIONAL'S FORMULA FOR SUCCESS™