

HENRY®

630 PeachPro™

High performance pressure sensitive adhesive for installing carpet tile in heavy traffic areas

Formerly known as PeachGlue™

Easy Application

Trowel, brush or roll-on for easy installation

Highly Versatile

Releasable or Permanent

Plasticizer Migration Resistant

Great for installing vinyl back carpet tile

Excellent Grab

Helps reduce product movement during installation

Cushion to Substrate

For double glue-down installations

630 HENRY®
PeachPro™



Pressure Sensitive

Flooring

Adhesive
"Peach Glue"

Adhesivo "Peach Glue"
sensible a la presión



Environmentally Compatible
Next Generation™

4 GALLONS (15.14 L.)



Pressure Sensitive Adhesive

THE PROFESSIONAL'S FORMULA FOR SUCCESS.

HENRY® 630 PeachPro™

The Professional's Formula For Success when installing carpet tile and carpet cushion to substrate in heavy traffic areas.

	MULTIPURPOSE PRES. SENS.		
	HENRY 620	HENRY 630	HENRY 660
Carpet Tile			
Non Vinyl-Back		BEST	
Vinyl-Back – Releasable	BETTER	BEST	
Vinyl-Back – Permanent		BEST	
Approved Carpet Cushions			
Cushion to Substrate		BEST	
Resilient Tile			
Vinyl (Solid Vinyl)			BEST
Wood			
Parquet			BETTER



NON VINYL-BACK CARPET TILE (RELEASABLE & PERMANENT), VINYL-BACK CARPET TILE (PERMANENT) AND CUSHION TO SUBSTRATE (PERMANENT)
SQ NOTCH 1/16D x 1/16W x 1/16A
200-250 sq ft (22-28 sq yds)/gal



VINYL-BACK CARPET TILE (RELEASABLE) AND CUSHION TO SUBSTRATE (RELEASABLE)
BRUSH, SHORT NAP ROLLER OR FLAT SIDE OF TROWEL.
300-450 sq ft (33-50 sq yds)/gal

SUBSTRATES:

HENRY 630 PeachPro Pressure Sensitive Flooring Adhesive will bond to all listed substrates but specific installation recommendations for the flooring should come from the manufacturer:

- Concrete
- Wood and wood underlayments; wood subfloors should be suspended
- Existing well-bonded resilient flooring; not perimeter bonded or cushion-backed; not over tile below grade
- Ceramic tile, terrazzo, marble, and polymeric poured floors
- Properly mixed and applied powder underlayments and embossing levelers
- Primed, poured-in-place gypsum subfloors
- Radiant heated subfloors where the surface temperature does not exceed 85°F (29°C)

INSTALLATION TIPS:

- Condition the area to be installed, adhesive, and flooring to 65°F (18°C) or above for 48 hours before, during, and for 48 hours after installation.
- Subfloor must be smooth, sound, dry, clean, and free dirt, wax, polish, paint, and all other foreign matter which may interfere in a good bond, including curing agents and sealers.
- Always run a calcium chloride and alkali test over concrete on any grade level or any other substrate over on or below grade concrete. For accurate results, curing agents must be removed in areas where tests will be run. Moisture test results should meet the flooring manufacturer's recommendations but should not exceed 3 pounds/1000 ft²/24 hours. Alkali readings should be 5 to 9.
- Stir any liquid on the surface into the adhesive and full spread using a brush, roller, or recommended trowel notching.
- For permanent installation of carpet tile, allow adhesive to set open until somewhat tacky but not dry to the touch. Lay carpet tile into adhesive. Cut, fit and reposition immediately.
- For permanent installation of cushion to substrate, set cushion into wet adhesive.
- For releasable installation allow the adhesive to set open until dry to the touch, approximately 45 to 60 minutes. When dry to the touch, the adhesive will be tacky with no transfer to fingers. Cut, fit, and reposition flooring. Henry 630 has unlimited working time.
- Roll the flooring in both directions using the recommended roller (normally 75-100 pounds).
- Remove wet adhesive residue using a clean, white cloth dampened with soapy water. Use mineral spirits for dried adhesive residue carefully following warnings on container.
- Restrict heavy traffic over carpet for 24-48 hours and do not expose to water from cleaning or other sources for a minimum of 30 days.

HENRY

The W. W. Henry Company
400 Ardex Park Drive
Aliquippa, PA 15001
Technical Support: 1-800-232-4832
Internet: wwhenry.com

HENRY Commitment

HENRY is committed to helping you get the best results in professionally installed floors. 60 Years of experience combined with our relationships with the leading resilient, wood and carpet manufacturers ensure that you receive the products and the support you need to complete the job successfully and profitably.

IPD-212-799

THE PROFESSIONAL'S FORMULA FOR SUCCESS.