





Bronze and Brass Gate & Check Valves

Illustrated Index

<p>Bronze Gate Valve Screw-in Bonnet • Full Port 200 lb. CWP</p>  <p>S or T29 Non-Rising Stem • Solid Wedge Sizes 1/2" - 2" Threaded or Solder Ends page 27</p>	<p>Brass Gate Valve Screw-in Bonnet • Full Port 200 lb. CWP</p>  <p>S or TI-8 Non-Rising Stem • Solid Wedge Sizes 1/4" - 4" Threaded or Solder Ends page 28</p>	<p>Bronze Check Valve Inline Lift Type 200 lb. CWP</p>  <p>S or T480 Sizes 3/8" - 2" Threaded or Solder Ends page 29</p>
<p>Brass Check Valve Swing Type 200 lb. CWP</p>  <p>S or TI-3 Sizes 1/2" - 3" Threaded or Solder Ends page 30</p>		