

# HENRY®



## 263 WeatherPro™

Our best outdoor carpet adhesive!

- Waterproof**  
After 2 hours
- Excellent Initial Grab**  
Reduces edge curl
- No Open Time Required**  
For immediate installation
- Ample Working Time**  
For outdoor carpet installations
- Excellent Bond Integrity**  
For permanent installations
- Excellent Trowelability**  
Easy to use, easy to trowel

For installing outdoor carpet and artificial turf -

The Professional's Formula For Success.™

WATERPROOF AFTER 2 HOURS  
FOR ALL WEATHER USE  
EXCELLENT LONG TERM BOND INTEGRITY  
GREAT FOR PATIOS, BOATS AND DECKS  
INDOOR USE ONLY

263 HENRY WeatherPro



Outdoor Carpet Adhesive

Adhesivo para alfombras exteriores

**⚠ DANGER**

EXTREMELY FLAMMABLE  
LIQUID AND VAPOR  
VAPOR MAY CAUSE  
FLASH FIRE  
READ CAREFULLY OTHER  
CAUTIONS ON BACK PANEL

**⚠ PELIGRO!**

LÍQUIDO Y VAPOR EXTREMADAMENTE INFLAMABLE.  
EL VAPOR PUEDE PROVOCAR INCENDIO REPENTINO  
LEA CUIDADOSAMENTE LAS DEMÁS  
PRECAUCIONES EN EL DORSO.

CUSTOMER SERVICE CENTER  
1-800-232-4832  
<http://www.wahenry.com>



ADHESIVE UNIT 1.35



**Outdoor Carpet Adhesive**

THE PROFESSIONAL'S FORMULA FOR SUCCESS™

# HENRY 263 WeatherPro™

**The Professional's Formula For Success™ when installing carpet outdoors. Henry 263 WeatherPro™ is waterproof within two hours after installation, and can be used in wide temperature ranges.**

	HENRY 263	HENRY 663
<b>Carpet</b>		
Indoor/Outdoor Carpet		BEST*
Outdoor Carpet	BEST*	BETTER*

\*outdoors only



#### SUBSTRATES:

**HENRY 263 WeatherPro™ Outdoor Carpet Adhesive** will bond to all substrates listed below but specific installation recommendations for the flooring should come from the manufacturer:

- Concrete
- Asphalt paving and other clean, sound paving surfaces; not asphalt roofing
- Exterior or marine grade plywood decking which is sound and not subject to deterioration; not plank decking or treated wood
- Aluminum boat decks which are clean and roughened
- Fiberglass which has been roughened
- Substrates which have been painted, stained, or otherwise coated must be tested to assure compatibility with the adhesive

#### INSTALLATION TIPS:

- This adhesive is for outdoor use only.
- 263 WeatherPro may be used in temperatures ranging from 45°F (4°C) to 100°F (38°C).
- Substrate must be smooth, sound, dry, clean, and free of excessive moisture and/or alkali. Remove dirt, wax, polish, paint, and all other foreign matter which may interfere with a good bond, including curing agents and sealers.
- Stir any liquid on the surface into the adhesive and full spread using the recommended trowel notching. Recommended trowel sizes are guidelines only, and are minimum requirements. Rough, porous concrete or asphalt paving and heavily textured carpet backings may require deeper notches. A 100% transfer of adhesive into the carpet backing, while maintaining full coverage of the substrate, must be obtained.
- Install carpet immediately into wet adhesive. Do not let adhesive skin over.
- Cut, fit, and reposition within 30 minutes. Working time will vary based on job conditions, substrate, temperature, and humidity.
- Lift a newly laid area occasionally to make sure adhesive is transferring fully to the back.
- Smooth the bonded area with firm pressure using a 2-foot length of carpet tube. You must use a light roller for polypropylene-backed carpets.
- Cut and seal all seams as recommended by the carpet manufacturer.
- Seams in rubber-backed goods may peak slightly after fitting, and small bubbles may appear in the field. These come from temporary swelling of the rubber back and will stay down when the adhesive starts to set.
- Clean adhesive residue from the surface using a clean, white cloth dampened with mineral spirits carefully following warnings on container.

Note: Henry 263 is not recommended for vinyl-backed or urethane-backed carpet.

## HENRY®

The W.W. Henry Company  
400 Ardex Park Drive  
Aliquippa, PA 15001  
(724) 203-8000

Customer Service and Technical Information  
1-800-232-4832

Visit our Web site: [wwhenry.com](http://wwhenry.com)

#### HENRY Commitment

HENRY is committed to helping you get the best results in professionally installed floors. 70 Years of experience combined with our relationships with the leading resilient, wood and carpet manufacturers ensure that you receive the products and the support you need to complete the job successfully and profitably.

IPD-202-205

# THE PROFESSIONAL'S FORMULA FOR SUCCESS™