


# detect



**A wireless PUZZLE transmitter that alerts any PUZZLE receiver when it hears an alarm.**



 **DETECT**



New external mic

**D**ETECT is a wireless alerting transmitter that picks up the sounds from a variety of sources (doorbells, telephones, smoke detectors, kitchen timers, etc.).

DETECT is placed right next to the device (e.g., doorbell) that the user needs to hear. The alarm is picked up by DETECT, and a signal is wirelessly sent to one or more of the PUZZLE receivers: CALL, FLASH, WAKE, POCKETVIB, LOOP, BEAM, and LINK.

Via a new separate external microphone DETECT can now pick up weak sound sources and sound sources in noisy environments.

Enjoy the security of up to seven DETECT transmitters in the house - one for each sound source.

DETECT runs on one battery, which will last approximately 10 years. It has a built-in battery tester so the user can check to see if the battery needs to be changed.

**Call +45 3917 7101**  
**Other resources available at [www.phonicear.dk](http://www.phonicear.dk)**



# observer

A wireless PUZZLE transmitter/pager that activates any PUZZLE receiver when the baby cries or the pager button is activated.



 OBSERVER



With OBSERVER, parents can safely put their child down for a nap, knowing that they will be alerted when their child awakens. OBSERVER's microphone detects when the child cries and transmits that information wirelessly to one or more of the PUZZLE receivers: CALL, FLASH, WAKE, POCKETVIB, LOOP, BEAM, and LINK.

OBSERVER can also be used as a pager. When its built-in push button is activated, a signal is sent to the PUZZLE receivers, paging the user.

OBSERVER can be used both inside and outside the house, within a range of up to 75 meters (246 feet).

OBSERVER runs on three alkaline batteries and has an approximate battery life of one year. It has a built-in battery tester so the user will know when the battery needs to be changed.

# call



The **PUZZLE** receiver that alerts with an audible sound.



 **CALL**



**C**ALL is a sound alerting device which receives alarm signals from the doorbell, telephone, smoke detector, etc., via the DETECT alerting transmitter. CALL also receives alarm signals from the OBSERVER baby alarm and pager. When CALL receives a signal, its loudspeaker converts it into an audible sound signal.

The sound signals can be adjusted to 16 different tones (frequencies), and are easily adjusted to the user's optimal frequency so others are disturbed as little as possible.

CALL has seven different signal patterns, one for each sound source. That way the user can easily identify which alarm has been activated.

An unlimited number of CALL receivers can be used at the same time. CALL can be mounted on the wall or placed on a table stand so it is portable.

CALL can be combined with a battery backup as a temporary power supply and for security in case of a power outage or an outage caused by fire.

**Call +45 3917 7101**

**Other resources available at [www.phonicear.dk](http://www.phonicear.dk)**



# flash

The **PUZZLE** receiver that uses light patterns to notify the user of visitors, calls, and alarms.



 FLASH



**F**LASH is a light alerting device which receives alarm signals from the doorbell, telephone, smoke detector, etc., via the DETECT alerting transmitter. FLASH also receives alarm signals from the OBSERVER baby alarm and pager. When FLASH receives a signal, it converts it into a bright, easily-seen halogen light pattern.

FLASH has seven different blink patterns, one for each sound source. That way the user can easily identify which alarm has been activated.

An unlimited number of FLASH devices can be used at the same time. FLASH can be mounted on the wall or placed on a table stand so it is portable.

# pocketvib

The **PUZZLE** receiver that vibrates to notify the user of a call or a visitor.



 **POCKETVIB**



**P**OCKETVIB is a small, powerful vibrator which receives alarm signals from the **OBSERVER** baby alarm and pager as well as from the doorbell, telephone, smoke detector, or other alarms using the **DETECT** alerting transmitter.

POCKETVIB uses vibration and light to alert the user. The vibrator has seven different vibration patterns, one for each sound source. That way the user can easily identify which alarm has been activated. It also has four differently-coloured lights on the front of the device that will alert the user.

It is wireless so the user can move freely around the house or be outside and still receive important alarms. The size and shape of a small pager, it fits easily in a pocket or may be clipped to the user's clothing. It has a range of up to 75 meters (246 feet).

POCKETVIB runs on batteries and has an approximate battery life of one year. It has a built-in battery tester so the user will know when the battery needs to be changed.

**Call +45 3917 7101**

**Other resources available at [www.phonicear.dk](http://www.phonicear.dk)**







# wake

The **Puzzle** receiver that vibrates when it's time to get up or another alarm is activated.



 WAKE



Now in black



**W**AKE is a vibrating alarm and alerting device which lets the user know when the alarm clock rings or when the smoke detector sounds by activating its powerful vibrator. Although WAKE plugs into an electrical outlet we do recommend using our battery backup in case of a power outage or an outage caused by fire.

WAKE is placed on the bedside table, right next to the alarm clock, and the vibrator is put underneath the pillow. WAKE's built-in microphone will detect the alarm once it sounds and activate the vibrator (it will also "hear" the smoke alarm from this position on the bedside table). The vibration pattern differs depending on what signal it is receiving, making it easy for the user to distinguish the alarm.

WAKE can be used alone as a wake-up system, or it can be used along with the DETECT alerting transmitter and OBSERVER baby alarm and pager. This allows the user to be informed by the WAKE vibrator for a wide variety of circumstances: when the telephone rings, when someone rings the doorbell, when the baby cries, etc.



Call +45 3917 7101

Other resources available at [www.phonicear.dk](http://www.phonicear.dk)

# shake awake

**A vibrating alarm clock suitable for travelling.**



**S**HAKE AWAKE is an alarm clock with a powerful built-in vibrator, designed for hearing-impaired or deaf people who need an effective alarm. Even when the user's hearing aids are out, the vibration ensures that they will wake up on time.

Designed to be durable, the clock is made of sturdy plastic. The alarm is easy to set and the display has large, distinct numbers and a light for nighttime viewing.

SHAKE AWAKE is placed under the pillow and fastened to the pillowcase by a small clip. In addition to its vibration, SHAKE AWAKE can also be set to produce an audible alarm.

SHAKE AWAKE is a flexible alarm solution that is suitable for use when traveling or for those who don't want to wake anyone else when their alarm goes off.

**Call +45 3917 7101**

**Other resources available at [www.phonicear.dk](http://www.phonicear.dk)**


# detect



**A wireless PUZZLE transmitter that alerts any PUZZLE receiver when it hears an alarm.**



 **DETECT**



New external mic

**D**ETECT is a wireless alerting transmitter that picks up the sounds from a variety of sources (doorbells, telephones, smoke detectors, kitchen timers, etc.).

DETECT is placed right next to the device (e.g., doorbell) that the user needs to hear. The alarm is picked up by DETECT, and a signal is wirelessly sent to one or more of the PUZZLE receivers: CALL, FLASH, WAKE, POCKETVIB, LOOP, BEAM, and LINK.

Via a new separate external microphone DETECT can now pick up weak sound sources and sound sources in noisy environments.

Enjoy the security of up to seven DETECT transmitters in the house - one for each sound source.

DETECT runs on one battery, which will last approximately 10 years. It has a built-in battery tester so the user can check to see if the battery needs to be changed.

**Call +45 3917 7101**  
**Other resources available at [www.phonicear.dk](http://www.phonicear.dk)**





# observer

A wireless PUZZLE transmitter/pager that activates any PUZZLE receiver when the baby cries or the pager button is activated.



 OBSERVER



With OBSERVER, parents can safely put their child down for a nap, knowing that they will be alerted when their child awakens. OBSERVER's microphone detects when the child cries and transmits that information wirelessly to one or more of the PUZZLE receivers: CALL, FLASH, WAKE, POCKETVIB, LOOP, BEAM, and LINK.

OBSERVER can also be used as a pager. When its built-in push button is activated, a signal is sent to the PUZZLE receivers, paging the user.

OBSERVER can be used both inside and outside the house, within a range of up to 75 meters (246 feet).

OBSERVER runs on three alkaline batteries and has an approximate battery life of one year. It has a built-in battery tester so the user will know when the battery needs to be changed.

# call



The **PUZZLE** receiver that alerts with an audible sound.



 **CALL**



**C**ALL is a sound alerting device which receives alarm signals from the doorbell, telephone, smoke detector, etc., via the DETECT alerting transmitter. CALL also receives alarm signals from the OBSERVER baby alarm and pager. When CALL receives a signal, its loudspeaker converts it into an audible sound signal.

The sound signals can be adjusted to 16 different tones (frequencies), and are easily adjusted to the user's optimal frequency so others are disturbed as little as possible.

CALL has seven different signal patterns, one for each sound source. That way the user can easily identify which alarm has been activated.

An unlimited number of CALL receivers can be used at the same time. CALL can be mounted on the wall or placed on a table stand so it is portable.

CALL can be combined with a battery backup as a temporary power supply and for security in case of a power outage or an outage caused by fire.

**Call +45 3917 7101**  
**Other resources available at [www.phonicear.dk](http://www.phonicear.dk)**

