

**RS-232 control USB A-A cable****RC5212MT:** 6ft (1.83mm), for 20 slot MultiTasker**RC5213MT:** 18in (457.2mm), for 20 slot MultiTasker**RS-232 control DB9 M (for MT) to DB9 F (for input) loop cable****RC5215MT:** 15in (381mm), for 2 MultiTasker enclosures**CB901-100:** 5ft (1.52m), for 5 19/20 slot Multi-Tasker enclosures**CB901-101:** 7.5ft (2.29m), for 7 19/20 slot Multi-Tasker enclosures**RS-232 control USB A (20 slot MT) to DB9 M (other MT) loop cable****RC5217MT:** 15in (381mm), for connecting 20 slot MT to other MT enclosure**TCP/IP to RS-232 adapter and web server****AC301-201****Judge override button for system shutdown****RC5205CV:** 50ft cable included