

MT112-105**1-In 3-Out Power Distribution With Current Sensor****Common features:**

- Programmable power sequence
- Independent control for each socket
- Status LED for each output
- 10 Amp loading
- Over-current/pre-programmed shutdown
- Read current on each connector
- North American version

Uses 2 slots in MT enclosure

MT112-106**1-In 6-Out Power Distribution With Current Sensor****Common features:**

- Programmable power sequence
- Independent control for each socket
- Status LED for each output
- 10 Amp loading
- Over-current/pre-programmed shutdown
- Read current on each connector
- North American version

Uses 4 slots in MT enclosure

MT112-107**1-In 3-Out Power Distribution With Current Sensor****Common features:**

- Programmable power sequence
- Independent control for each socket
- Status LED for each output
- 8.5 Amp loading
- Over-current/pre-programmed shutdown
- Read current on each connector
- International version

Uses 3 slots in MT enclosure

MT112-108**1-In 6-Out Power Distribution With Current Sensor****Common features:**

- Programmable power sequence
- Independent control for each socket
- Status LED for each output
- 8.5 Amp loading
- Over-current/pre-programmed shutdown
- Read current on each connector
- International version

Uses 4 slots in MT enclosure