Soil Pipe Puller 568



To Assemble Pipe

Place yoke behind hub, fasten chain through slot and hook on to end of pipe and pull handle to join.



Horizontal Pipe Assembly

To Disassemble Fittings and Pipe Place yoke in front of hub,

Place yoke in front of hub, hook chain around fitting, and place in slot at end of bar. Push handle to release fitting



Fitting Disassembly



Vertical Pipe Assembly



Pipe Disassembly