

P-1 Photo Presenter

V-LINK USB

Never before has there been such an easy way to add visuals to your live performances.

An incredible photo player with MP3 or MIDI file playback. With its large touch-screen user interface the P-1 is ideal for VJ performances or visual events.



The P-1 is an incredible new photo player for visual performance, audio & MIDI playback.

Audio can also be linked to picture files, allowing the P-1 to playback appropriate music or commentary for the selected image. The P-1 has both line & mic input, allowing the user to record audio directly into the P-1. Pictures can also be loaded directly into the P-1 from the PC memory card or via USB, allowing you to quickly import pictures from your digital camera for your performance or presentation.

Built-in title maker.


The P-1 has a built in virtual keyboard for creating titles. You can key them over your pictures for captions, announcements, names of performers, and any other purpose - all without the need of a computer.



Support for MP3 and MIDI.

The P-1 supports both MP3 and MIDI. The VariPhrase technology allows you to freely and independently control the tempo and pitch of MP3 playback. It includes a tempo control knob for adjusting the playback speed in real time, and images can be triggered in time with the sequence for a more impressive performance. This lets you modify the character of the music appropriately for your situation. The P-1 is also ideal as a MIDI sequence player.

Connections



Using the P-1 with the V-1.

The P-1 and the V-1 4-channel video mixer are the same size and follow the same design concept. By using the P-1 in conjunction with the V-1 you can overlay titles on live scenes of the performance.

V-LINK is a function that makes it easy to "perform video" in conjunction with music. It's easy to use a V-LINK compatible device to remotely control the P-1. V-LINK lets you perform a wide variety of video effects that are linked with your musical performance.



P-1 Specifications

•**Video Format:** NTSC or PAL •**Display:** 320 x 240dots, 5.7 inch Color Graphic LCD with Touch Panel •**Video Output:** Composite=RCA phono type S-Video=4-pin mini DIN type •**Audio Input:** LINE RCA phono type, MIC 1/4 inch phono type •**Audio Output:** LINE RCA phono type, PHONES stereo miniature phono type •**MIDI IN:** 5-pin DIN type •**MIDI OUT:** 5-pin DIN type •**USB:** Ver.1.1 (mass storage, supports Windows and Macintosh), PC Card (supports PC card adaptors for Microdrive, SmartMedia, CompactFlash, etc.) •**Maximum Photos:** 240 photos total: up to 75 photos (NTSC) / 53 photos (PAL) per album •**Maximum Narrations:** 240 narrations •**Memory:** 64MB (Flash ROM) •**File Format:** JPEG, BMP, WAV •**Power Supply:** DC 9V (AC Adaptor) •**Current Draw:** 800mA •**Dimensions (folding bottom stand):** 294 (W) x 218 (D) x 87 (H) mm •**Weight (excluding AC Adaptor):** 2.2kg •**Accessories:** Photo/Sound/BGM CD-ROM, S-Video Cable (1.5m)