


## 28 Series - Designer Style Wall Plates

**28-120**

**STEREO A+B SPEAKER SWITCH**

White plastic insert plate. Power rating is 50 watts. Common ground switching. Includes mounting hardware.



### Single Designer Style Speaker Selector Inserts

**28-128**

**HEADPHONE JACK AND SPEAKER SWITCH**


White plastic insert plate. Push switch and 1/4" Stereo headphone jack. 100 watts cont. / 150 watts peak. Includes mounting hardware. Input and output terminals on the back. Contains protective dropping resistor for headphone output jack.



**28-129**

**A/B OR A+B SPEAKER SWITCH**

White plastic insert plate. Rotary type switch. Screw-to-connect terminal blocks. 100 watts cont. / 150 watts peak. Includes mounting hardware.



**28-130**

**SPEAKER SELECTOR FOR 2 PAIRS OF SPEAKERS**

White plastic insert plate. Push type switch. Screw-to-connect terminal blocks. 100 watts cont. / 150 watts peak. Common ground switching. Includes mounting hardware.



**28-131**

**A-B SELECTOR FOR AMPLIFIER OR SPEAKER SWITCHING WITH ISOLATED GROUNDS**

Plastic insert plate fits into single gang standard electrical junction box. Removable screw to connect terminal blocks. Accepts up to 14 awg. wire. Power handling of 55 watts per channel/max. Isolated ground terminals for amplifier protection. Easy to read terminal identification. Break before making switching.

