

Become a 60 Second *e*³ SERIES™ Expert

Everything you need to know to build a basic eMerge system in less than a minute.

www.linearcorp.com/emerge-browser-managed-access-systems.php

One-Door System


- A** One (1) **ES-1MB**¹ 1-Door, 1-Mullion Mount Reader Essential Access System Bundle (Part # 620-100219)
- B** One (1) **ProxCARD II** 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARD II)



eMERGE
ESSENTIAL

Two-Door System


- A** One (1) **ES-1MB**¹ 1-Door, 1-Mullion Mount Reader Essential Access System Bundle (Part # 620-100219)
- B** One (1) **ES-1DLB**¹ Single Door License with Reader Bundle (Part # 620-100221)
- C** One (1) **ProxCARD II** 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARD II)



eMERGE
ESSENTIAL

Three-Door System

- A** One (1) **ES-1MB**¹ 1-Door, 1-Mullion Mount Reader Essential Access System Bundle (Part # 620-100219)
- B** Two (2) **ES-1DLB**¹ Single Door License with Reader Bundle (Part # 620-100221)
- C** One (1) **ProxCARD II** 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARD II)



eMERGE
ESSENTIAL

Four-Door System

- A** One (1) **ES-4MB**² 4-Door, 4-Mullion Mount Reader Essential Access System Bundle (Part # 620-100220)
- B** One (1) **ProxCARD II** 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARD II)



eMERGE
ESSENTIAL

Linear[®]

800.421.1587
www.linearcorp.com

¹ Includes One (1) **P-300HA** 125 kHz, HID-Compatible, Proximity Access Card Reader (Part # 620-100224)


² Includes Four (4) **P-300HA** 125 kHz, HID-Compatible, Proximity Access Card Readers (Part # 620-100224)

Become a 60 Second Expert

Everything you need to know to build a basic eMerge system in less than a minute.

Six-Door System


- A** One (1) **EL36-4MB**² 4-Door, 4-Reader Elite Access System Bundle (Part # 620-100259)
- B** One (1) **ACM2DB**³ 2-Door, 2-Reader ACM with Reader Bundle (Part # 620-100270); ACM mounts inside either the ES or EL standard metal enclosure
- C** One (1) **ProxCARD II** 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARD II)





Eight-Door System

- A** One (1) **EL36-4MB**² 4-Door, 4-Reader Elite Access System Bundle (Part # 620-100259)
- B** One (1) **ACM4DB**² 4-Door, 4-Reader Access System Bundle (Part # 620-100272); ACM mounts inside either the ES or EL standard metal enclosure
- C** One (1) **ProxCARD II** 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARD II)





Ten-Door System

- A** One (1) **EL36-4MB**² 4-Door, 4-Reader Elite Access System Bundle (Part # 620-100259)
- B** One (1) **EXN-2MB**³ 2-Door, 2-Reader Access System Expansion Bundle (Part # 620-100280)
- C** One (1) **ACM4DB**² 4-Door, 4-Reader Access Control Module Bundle (Part # 620-100272); ACM mounts inside either the ES or EL standard metal enclosure
- D** One (1) **ProxCARD II** 25-Pack, 125 kHz, Wiegand Proximity Access Cards (Part # ProxCARD II)





ES = eMerge Essential

EL = eMerge Elite

² Includes Four (4) **P-300HA** 125 kHz, HID- and AWID-Compatible, Proximity Access Card Readers (Part # 620-100224)

³ Includes Two (2) **P-300HA** 125 kHz, HID- and AWID-Compatible, Proximity Access Card Readers (Part # 620-100224)

To try an E3-Series eMerge system, go to: www.linearcorp.com/try-emerge-essential.php
For License-to-Go™ upgrades, go to: www.e3upgrade.com

Linear®

800.421.1587 | www.linearcorp.com