



sensate™

TOUCHLESS KITCHEN FAUCET

KOHLER. Faucets. Live Bold.

THE BOLD LOOK
OF **KOHLER**®



The Response™ technology of the Sensate™ touchless kitchen faucet responds to your every move, leaving you to wonder how you ever prepped, cleaned and cooked without it.



Sensate kitchen faucet frees your hands so that you can flow through your kitchen tasks, like getting down and dirty with food prep, without pausing to turn the faucet handle on and off. And you don't have to worry about spreading the mess, and germs, to the rest of the kitchen.




The state-of-the-art sensor responds in 20 milliseconds. Simply wave your hand or pot or pan through the sensor window for reliable on/off operation every time.



AUTO SHUTOFF
Sensate[™] features an automatic shutoff safeguard.




Sensate™
features
DockNetik™,
our new
magnetic
docking
system that
secures the
sprayhead in
place.



[KOHLER.com/Sensate](https://www.kohler.com/Sensate)



**WHITE CUPCAKES
WITH CHOCOLATE
GANACHE FROSTING**
Get the The American
Club® resort recipe at
[KOHLER.com/Sensate](https://www.kohler.com/Sensate).



BEAUTY & BRAWN
Sleek design meets a workhorse mentality to help you flow more cleanly and easily through your kitchen.




New

Response™ Technology
Delivers convenient, reliable and hygienic control with a swipe of your hand.



New

DockNetik™
Our new docking system features magnets positioned in the spout to securely lock the sprayhead in place.



ProMotion™ Technology
The braided nylon hose ensures it won't kink or tangle, and the swiveling ball joint provides smooth operation with minimal effort.



Two-Function Sprayhead
Spray and stream functions help to make light work of kitchen tasks.



Easy Temperature Control
Adjust the water temperature with the handle while the faucet is in use.

New

Response™ Technology

Delivers convenient and hygienic control – freeing your hands to tackle kitchen tasks while reducing the threat of cross-contamination.

New

DockNetik™

Our new magnetic docking system secures the sprayhead in place.

LED

Lets you know it's operational and ready to go.

Battery-Free

AC power means no batteries to replace.

Manual Override

The faucet can be operated manually in the event of a power loss.



The sensor window begins at the underside of the spout and extends six inches towards the base.

Wave your hand through the beam to activate the water stream.

sensate™ TOUCHLESS KITCHEN FAUCET

Finish Options

(CP)

(VS)



Sensate Touchless Kitchen Faucet in Polished Chrome

With Black Bonnet

K-72218-B7-CP

With Polished Chrome Bonnet

K-72218-CP



Sensate Touchless Kitchen Faucet in Vibrant® Stainless

With Black Bonnet

K-72218-B7-VS

With Vibrant Stainless Bonnet

K-72218-VS



Touchless Operation

Delivers convenient and hygienic control



Lasting Finish

Resists corrosion & wear



Battery-Free

AC power means no batteries to replace



Durable Ceramic Valves

A lifetime of exceptional performance



Secure Magnetic Docking

Sprayhead securely locks into place



Easy Clean

Wipes clean with a wet cloth

For more information and FAQs, visit KOHLER.com/Sensate.



THE BOLD LOOK
OF **KOHLER**®

KOHLER® Faucets. *Live Bold.*

Form 13-1403-0113
© 2013 Kohler Co.
Kohler, Wisconsin 53044
Printed in U.S.A.
1-800-4-KOHLER
(1-800-456-4537)