

# Audio Distribution System



The Liberty Audio Distribution System delivers whole home audio from one or four sources to four or eight locations.

Since the amplification is done after the receiver, at the volume control, it permits true individual volume and source control at each location.

**WHY WAIT!**  
**Use The Website**  
**libertycable.com**

Liberty Audio Distribution: Unlike other structured wiring systems on the market that accept only one audio source for distribution via CAT5 throughout the home, the Liberty system distributes four different audio sources to four or eight zones in the home. Individual volume controls allow the user to bypass any of the four audio source.



## Audio Distribution Module

| Part No.   | Audio Sources | MAX Location | DC power Input | Input Connector | Output Connector | Dimension Length x Height | Infrared Control |
|------------|---------------|--------------|----------------|-----------------|------------------|---------------------------|------------------|
| HAA-1404   | Four          | 4            | 12VDC          | Terminal Block  | 110 IDC          | 6.3"x3"                   | No               |
| HAA-1408   | Four          | 8            | 12VDC          | Terminal Block  | 110 IDC          | 6.3"x3"                   | No               |
| HAA-1404IR | Four          | 4            | 12VDC          | Terminal Block  | 110 IDC          | 6.3"x3"                   | Yes              |
| HAA-1408IR | Four          | 8            | 12VDC          | Terminal Block  | 110 IDC          | 6.3"x3"                   | Yes              |

## Stereo Volume Control

| Part No. | Output Power | Speaker Impedance | Line in (3.5mm Local component socket) | Audio Source Selector LED Display | Volume Control | Infrared Control |
|----------|--------------|-------------------|--|-----------------------------------|----------------|------------------|
| SV-60    | 5W+5W        | 8 ohm             | Yes                                    | Yes/4 Source                      | Continuous     | No               |
| SV-60IR  | 5W+5W        | 8 ohm             | Yes                                    | Yes/4 Source                      | Continuous     | Yes              |
| SV-61    | 5W+5W        | 8 ohm             | Yes                                    | Yes/4 Source                      | Continuous     | No               |



SV-60

SV-60IR

SV-61

ISK-358

Stereo Wallplate Connector

Must be used for Stereo Line Level input

CALL TODAY TO PLACE YOUR ORDER

libertycable.com

**800-530-8998**  
 MOST ORDERS SHIP SAME DAY



**Don't Buy WIRE**  
**MAKE MORE MONEY WITH LIBERTY**  
**SELL IT!**

Professional Accessories