

High Purity Laboratory Faucets

GNF 10 VB



GNF 30 VB



Recommended Specifications


Welded Assembly Deck mounted Laboratory Faucet with integral vacuum breaker manufactured from Virgin unpigmented resin.


☐ Polypropylene per ASTM D 4101 ☐ PVDF per ASTM D 3222.

Recommended Specifications

Threaded Assembly Deck mounted Laboratory Faucet with integral vacuum breaker manufactured from Virgin unpigmented resin.

☐ Polypropylene per ASTM D 4101 ☐ PVDF per ASTM D





Recommended Specifications

Welded Assembly Wall mounted Laboratory Faucet with integral vacuum breaker manufactured from Virgin unpigmented resin.


☐ Polypropylene per ASTM D 4101 ☐ PVDF per ASTM D

Recommended Specifications

Threaded Assembly Wall mounted Laboratory Faucet with integral vacuum breaker manufactured from Virgin unpigmented resin.

☐ Polypropylene per ASTM D 4101 ☐ PVDF per ASTM D


High Purity Laboratory Faucets



Recommended Specifications

Welded Assembly Deck mounted Laboratory Faucet with manufactured from Virgin unpigmented resin.


Polypropylene per ASTM D 4101 ☐ PVDF per ASTM D



Recommended Specifications

Welded Assembly Wall mounted Laboratory Faucet manufactured from Virgin unpigmented resin.


Polypropylene per ASTM D 4101 ☐ PVDF per ASTM D 3222.



Recommended Specifications

Threaded Assembly Deck mounted Laboratory Faucet manufactured from Virgin unpigmented resin.

Polypropylene per ASTM D 4101 □ PVDF per ASTM D




Recommended Specifications

Threaded Assembly Wall mounted Laboratory Faucet with manufactured from Virgin unpigmented resin.

Polypropylene per ASTM D 4101 ☐ PVDF per ASTM D

Recirculating Laboratory Faucets

Recirculating Faucet




Recirculating Faucet PVDF

Deck mounted Recirculating Laboratory Faucet manufactured from Virgin unpigmented PVDF resin per ASTM D 3222. Inlet and Outlet to be 1/2" female pipe thread, and molded into base. Unit to be activated by needle valve of same resin, mounted at point of release of fluid.

Recirculating Faucet PP

Deck mounted Recirculating Laboratory Faucet manufactured form Virgin unpigmented Type I Homopolymer Polypropylene per ASTM D 4101. Inlet and Outlet to be 1/2" female pipe thread, and molded into base. Unit to be activated by needle valve of same resin, mounted at point of release of fluid.



www.orionfittings.com Laboratory Faucets 21

Flow of the Recirculating Faucet


Water runs through inlet pipe, up the inner tube of the faucet and into the needle valve. If water is not diverted through the hose barb and out the faucet, it will run back out the outside of the inner faucet tube and out the outlet pipe on the bottom side of the faucet. INTERIOR TUBE \odot VIEW A-A DIVERTER HOSE BARB (R.F. Interior Tube **Outlet Pipe** Inlet Pipe Water flows out thru outside of inner tube Water Pressure pushes water thru and out of the side the inlet outlet. into the head and then out the faucet. **Outlet Pipe** Inlet Pipe inside of inner tube at bottom of faucet

Ultra Pure Water Flex Connector

Orion's flex connector simplifies the connection between the rigid piping in the wall and the base of the faucet. This PVDF tubing connection allows you to connect the faucet and the rigid piping with the same dependable materials as the rest of the system. These connectors are used in both Polypropylene and PVDF systems. The threaded connection can be either male or female allowing you to transition one connection. The threaded connection eliminates the need for special tools under the countertop.

Recommended Specification

Flex connectors shall be manufactured from virgin PVDF resin per ASTM D 3222. PVDF tubing shall be 1/2" in diameter. Threaded connectors shall be manufactured of same resin.



Ultra Pure Water Flex Connector	
Description	Part Number
· · · · · · · · · · · · · · · · · · ·	
12" lg x % F.I.P. x ½ F.I.P.	38F-12-12F
12" lg x ¾ F.I.P. x ½ M.I.P.	38F-12-12M
12" lg x % M.I.P. x ½ F.I.P.	38M–12–12F 38M–12–12M
12" lg x ¾ M.I.P. x ½ M.I.P.	*****
12" lg x ½ F.I.P. x ½ F.I.P.	12F-12-12F
12" lg x ½M.I.P. x ½M.I.P.	12M-12-12M
12" lg x ½ M.I.P. x ½ F.I.P.	12M-12-12F
18" lg x ¾ F.I.P. x ½ F.I.P.	38F-18-12F
18" lg x % F.I.P. x ½ M.I.P.	38F-18-12M
18" lg x ¾ M.I.P. x ½ F.I.P.	38M-18-12F
18" lg x % M.I.P. x ½ M.I.P.	38M-18-12M
18" lg x % F.I.P. x ½ F.I.P.	12F–18–12F
18" lg x % M.I.P. x ½ M.I.P.	12M-18-12M
18" lg x % M.I.P. x ½ F.I.P.	12M-18-12F
is ig x / (iiii x / / 2 i iii i	
24" lg x % F.I.P. x ½ F.I.P.	38F-24-12F
24" lg x ¾ F.I.P. x ½ M.I.P.	38F-24-12M
24" lg x % M.I.P. x ½ F.I.P.	38M-24-12F
24" lg x % M.I.P. x ½ F.I.P.	38M-24-12M
24" lg x ½ F.I.P. x ½ F.I.P.	12F-24-12F
24" lg x ½ M.I.P. x ½ M.I.P.	12M-24-12M
24" lg x ½M.I.P. x ½F.I.P.	12M-24-12F
24" lg x % M.I.P. x ½ F.I.P.	38M-24-12M
36" lg x 3/8 F.I.P. x 1/2 F.I.P.	38F-36-12F
36" lg x 3/8 F.I.P. x 1/2 M.I.P.	38F-36-12M
36" lg x 3/8 M.I.P. x 1/2 F.I.P.	38M-36-12F
36" lg x 3/8 M.I.P. x 1/2 M.I.P.	38M-36-12M
36" lg x 1/2 F.I.P. x 1/2 F.I.P.	12F-36-12F
36" lg x 1/2 M.I.P. x 1/2 M.I.P.	12M-36-12M
36" lg x 1/2 M.I.P. x 1/2 F.I.P.	12M-36-12F

www.orionfittings.com Laboratory Faucets 23