


Heat Exchanger Tee: XT

	т	Тх	Dimensions — inches										
Part	Tube	Tube		в									
Number*	0.D.	0.D.	Α	Hex Flat	Вx	С	D	E min	Ex	G	Gx	М	Mx
4XT2[]BR4	1/4	1/8	2.02	9/16	7/16	7/16	.64	.19	.13	.72	.66	1.05	.97
8XT4[]BR4	1/2	1/4	2.73	7/8	9/16	11/16	.97	.42	.25	.97	.97	1.44	1.30
8XT4[]BR8	1/2	1/4	2.73	7/8	9/16	11/16	.97	.42	.25	.97	.91	1.44	1.23




Special Ordering Instructions:

Heat Exchanger Tees are available in other fractional and metric sizes by special order. Ask your HOKE distributor for price and availability information. Specify "Heat Exchanger Tee" followed by quantity and the desired tube connection sizes.

1/2" 1/4" * 1/2"

Standard Fitting

Example									
8XT4[]BR8									
1. Jacket and tubing O.D.									
2. Process tubing O.D.									
Specify material									
4. Branch tubing O.D.									
5. Metric									



Ordering Instructions

Heat Exchanger Tees can be created with standard union tees and full port reducers to allow process tubing to be inserted into and through the jacket tubing.

To order a full port reducer, add the letter "T" to the core reducer part number.

Example: 8RT12 316

^{* []} see page 6 for material specifications.