

HENRY®

971 PlankPro™

Moisture-cured urethane wood adhesive for installing solid wood plank and strip, wood parquet, and engineered wood plank and strip

Extremely Versatile

Use for all manufacturers' wood flooring installations

Contains No Water

Will not cause warping or peaking

Long Working Time

Allows for product repositioning

Excellent Bond Strength

Perfect for commercial and residential solid wood flooring applications

Excellent Initial Tack

Holds flooring securely during installation

One-Part Product

Easy to use, no mixing

Easy Cleanup - New HENRY 972 Urethane Adhesive Remover

Saves time

Size Available

3.5 gallon

The leading solid wood plank and strip up to 5/8" thick.
• Most commercial and residential applications.
The Professional's Formula For Success.™

NO WATER TO WET WOOD
• ONE-PART, NO MIXING
• EXCELLENT INITIAL TACK
• CAN BE USED FOR ALL MANUFACTURERS' WOOD INSTALLATIONS
• CLEAN UP WITH HENRY 972



971 HENRY® PlankPro™

Moisture Cure Urethane Wood Adhesive

Adhesivo de Uretano Curable de Humedad Para Madera

⚠ WARNING

EYE AND SKIN IRRITANT.
MAY CAUSE DERMATITIS AND ALLERGIC
RESPONSES. POTENTIAL SKIN AND/OR
RESPIRATORY SENSITIZER. READ CAREFULLY
OTHER CAUTIONS ON BACK PANEL.

⚠ ADVERTENCIA

IRRITANTE A LA PIEL Y A LOS OJOS.
PUEDE CAUSAR DERMATITIS Y REACCIONES ALÉRGICAS.
POSIBLE SENSIBILIZADOR DE LA PIEL Y/O RESPIRACION.
LEA CUIDADOSAMENTE OTROS PRECAUCIONES EN EL
FRENTE DE ATRAS.

3.5 GALLONS (13.25 L.)



Wood
Adhesive



THE PROFESSIONAL'S FORMULA FOR SUCCESS™

HENRY 971 PlankPro™

HENRY 971 PlankPro is a one-part moisture-cured urethane wood adhesive designed for the installation of all manufacturers solid wood plank and strip (up to 3/8" thick), wood parquet, and engineered wood plank and strip in commercial and residential applications. PlankPro contains no water and has excellent bond strength and initial tack. Cleanup is easy with HENRY 972 Urethane Adhesive Remover.

	HENRY 871	HENRY 971
Wood		
Parquet	BEST	BEST
Engineered Plank and Strip	BEST	BEST
Solid Wood Plank and Strip*		BEST

* Up to 3/80 thick



SUBSTRATES:

HENRY 971 PlankPro™ Moisture Cure Urethane Wood Adhesive will bond to all substrates listed below but specific installation recommendations for the wood flooring should come from the manufacturer:

- Concrete
- Wood and wood underlayments; wood subfloors should be suspended
- Existing well-bonded resilient flooring; not perimeter-bonded or cushion-backed
- Properly mixed and applied powder underlayments and embossing levelers
- Primed, poured-in-place gypsum subfloors
- Radiant-heated subfloors where the surface temperature does not exceed 85°F (29°C)

INSTALLATION TIPS:

- Read wood flooring installation instructions before spreading the adhesive.
- Condition the area to be installed, adhesive, and flooring to 65°F (18°C) or above for 48 hours before, during and for 48 hours after installation.
- All concrete slabs should be completely cured and dry.
- Subfloors must be flat within 3/16" in 10 ft. or 1/8" in 6 ft.
- Fill low spots with a Portland cement-based leveling compound with a minimum of 3000 psi and allow to dry.
- Substrate must be sound, smooth, dry, clean, and free of excessive moisture and/or alkali. Remove dirt, wax, loose paint, and all other foreign matter which may interfere with a good bond.
- Always run a calcium chloride and alkali test over concrete on any grade level or any other substrate over on or below grade concrete. For accurate results, curing agents must be removed in areas where tests will be run. Moisture test results should meet the flooring manufacturer's recommendations but should not exceed 3 pounds/1000 ft²/24 hours. Alkali readings should be 5 to 9.
- Full spread adhesive using the recommended trowel. Do not spread more adhesive than can be covered with wood within 45 minutes to one hour.
- Installation of the wood should begin immediately. Working time may vary due to air movement, humidity, subfloor porosity and temperature.
- Do not allow a heavy film to form on the surface of the adhesive. Should this occur, remove the old adhesive and spread fresh adhesive.
- Press wood into adhesive. Occasionally check the back of a board for adequate adhesive transfer.
- Remove adhesive with HENRY 972 Urethane Adhesive Remover. HENRY 971 is easiest to remove in the wet state. Cured adhesive is more difficult to remove.
- Avoid foot traffic for 24 hours after installation.
- Do not apply finishes to unfinished products until adhesive is properly cured.

HENRY

The W.W. Henry Company
400 Ardex Park Drive
Aliquippa, PA USA 15001
Customer Service Center: 1-800-232-4832
Visit our Website: www.wwhenry.com

IPD-311-700

HENRY Commitment

HENRY is committed to helping you get the best results in professionally installed floors. Sixty years of experience combined with our relationships with the leading resilient, wood and carpet manufacturers ensure that you receive the products and the support you need to complete the job successfully and profitably.

THE PROFESSIONAL'S FORMULA FOR SUCCESS™