



## DUAL AUTOREVERSE CASSETTE DECK



**DUAL  
AUTOREVERSE  
Cassette Deck  
Dual Deck Play  
Tape Dubbing  
Rack Mountable**

**Rack Mounting  
Rack Kit PRM860**

**PM600R**

### General Information


- ❑ Autoreverse and Repeat Playback on Deck 2 only
- ❑ Autoreverse Bi-Directional Recording on Deck 2
- ❑ Dolby\* B Noise Reduction
- ❑ Multifunction Remote Capable with Optional Control
- ❑ Dual Digital Electronic Tape Index Counter
- ❑ Automatic Tape Bias Selector on Deck 2
- ❑ Large Knob Record Level Control for Deck 2
- ❑ Normal and High Speed Dubbing Capability
- ❑ Pause Control on Deck 2
- ❑ Full Automatic Stop Capability
- ❑ Optional Rack Mounting

\*Dolby is a Trademark of Dolby Laboratories Licensing Corporation

### Specifications

Track System:	4 Track, 2 Channel Stereo
Frequency Response:	
Chrome Tape	40 - 15,000 Hz
Normal Tape	40 - 14,000 Hz
Signal to Noise Ratio:	
3% THD Level	56 db NR Off (Weighted)
over 5 KHz	65 db Dolby* B NR
Line Input:	100 Mv at 50 K ohm
Output Level:	460 Mv at 50 K ohm
Heads:	
Tape Speed:	4.76 cm/sec, 17/8 IPS
Hi-Speed Dubbing	9.5 cm/sec, 3-3/4 IPS
Wow and Flutter:	0.3% WRMS
Timer	Record - Play
Power Requirement:	120 Volt - 60 Hz (or 230V, 50Hz)
Power Consumption:	15 Watt
Terminations:	RCA Standard Jacks
Housing Finish:	Matte Black
Dimensions:	171/8" W., 53/4" H., 113/4" D. (435 X 145 X 290 mm)
Net Weight:	9 Lbs, (3.9 Kg)
<b>Optional Accessories:</b>	
Rack Mounting Kit:	Model PRM860 Rack Kit (3U)
Remote Control:	Model PRC 544 Infrared


*Engineering leadership in sound products since 1931*



**Front Panel Controls**

- |                                |                                |
|--------------------------------|--------------------------------|
| 1) Power Switch                | 11) DECK 2 PAUSE Button        |
| 2) DECK 1 STOP Button          | 12) RECORD Button(Deck 2 only) |
| 3) DECK 1 PLAY Button          | 13) REC (Record) LEVEL Control |
| 4) DECK 1 Rewind Button        | 14) DECK 1 Cassette Holder     |
| 5) DECK 1 Fast Forward Button  | 15) DECK 2 Cassette Holder     |
| 6) DECK 2 STOP Button          | 16) REVERSE MODE Switch        |
| 7) DECK 2 Reverse Play Button  | 17) DUBBING SPEED Buttons      |
| 8) DECK 2 Forward Play Button  | 18) Display Window             |
| 9) DECK 2 Rewind Button        | 19) DOLBY NR Select Switch     |
| 10) DECK 2 Fast Forward Button |                                |

**Rear Panel**



**Decks Function Description**

**DECKS OPERATION**

DECK 1 is not an Autoreverse Deck. To play both sides the Cassette must be reversed manually.

DECK 2 is a fully Autoreverse Deck in both Playback and Record.

CONTINUOUS PLAYBACK - If a cassette is placed in Deck 1 and a cassette is placed in Deck 2 and the Mode Switch is in REVERSE after pressing the Play Button the cassette in Deck 1 will play to the end on one side. The Cassette in Deck 2 will automatically starts to play continuously on both sides and after 5 times it will stop.

DUBBING - Since Deck 1 is not an Autoreverse Deck the Dubbing process will stop when Deck 1 reaches the end of the cassette on side 1. To continue on Side 2 the cassette must be reversed manually and the Dubbing process re-started.



*since 1931*

**PASO SOUND PRODUCTS, INC.**  
 4750F GOER DRIVE  
 CHARLESTON, SOUTH CAROLINA 29406-6511 USA  
 Phone: 843 308 9005 - Fax: 843 308 0904  
 EMAIL: info@pasosound.com - URL: www.pasosound.com

FORM NT 249    RV 1.0    Printed in USA

**AUTHORIZED DISTRIBUTOR**

