
## Liberty

ACTIVELINX<sup>TM</sup> PLATES & PANELS

## Liberty ActiveLinx<sup>™</sup> Plate Configuration

Liberty's ActiveLinx<sup>TM</sup> Plate (LAP) configuration guide is the easiest way to select the correct plate functionality for your AV project. Start by determining both the plate finish and overall plate size for your project. Next select the set of ActiveLinx<sup>TM</sup> components and finally select the connectors sets by row. As the example shows, our plate numbering system provides you with complete design flexibility.



3